




## USER MANUAL

---

### Hybrid Inverter SSL-8K-24K-P3EU Series

# CONTENTS

|                                                   |    |
|---------------------------------------------------|----|
| 1. About This Manual .....                        | 1  |
| 1.1 Applicable Model .....                        | 1  |
| 1.2 Target Group .....                            | 1  |
| 1.3 Symbol Definition .....                       | 1  |
| 2. Safety Precaution .....                        | 1  |
| 2.1 General Safety .....                          | 1  |
| 2.2 PV String Safety .....                        | 2  |
| 2.3 Inverter Safety .....                         | 2  |
| 2.4 Battery Safety .....                          | 3  |
| 2.5 Personal Requirements .....                   | 3  |
| 2.6 EU Declaration of Conformity .....            | 3  |
| 3. Product Introduction .....                     | 4  |
| 3.1 Product Features .....                        | 4  |
| 3.2 Working Mode .....                            | 6  |
| 3.3 Appearance .....                              | 7  |
| 3.4 System Diagram .....                          | 12 |
| 4. Check and Storage .....                        | 12 |
| 4.1 Check Before Receiving .....                  | 12 |
| 4.2 What's in the box? .....                      | 13 |
| 4.3 Storage .....                                 | 14 |
| 5. Installation .....                             | 14 |
| 5.1 Installation Requirements .....               | 14 |
| 5.2 Inverter Installation .....                   | 17 |
| 6. Electrical Connection .....                    | 18 |
| 6.1 Safety Precaution .....                       | 18 |
| 6.2 Parallel connection notice .....              | 19 |
| 6.3 Connection Port Description .....             | 19 |
| 6.4 PE Cable Connection .....                     | 20 |
| 6.5 PV Connection .....                           | 21 |
| 6.6 EPS and Grid,Generator Connection .....       | 22 |
| 6.7 Battery Connection .....                      | 23 |
| 6.8 Communication Cable Installation .....        | 25 |
| 6.9 CT Connection .....                           | 28 |
| 6.10 Meter Connection .....                       | 29 |
| 6.11 Wiring System for Inverter .....             | 30 |
| 6.12 Wiring System for Diesel Generator .....     | 33 |
| 6.13 Three phase parallel connection system ..... | 34 |
| 7. Wi-Fi&BLE stick installation .....             | 35 |
| 7.1 Indication .....                              | 35 |
| 7.2 Install the Wi-Fi&BLE stick .....             | 36 |
| 7.3 Web/APP .....                                 | 36 |
| 7.4 Wi-Fi Connection .....                        | 36 |
| 7.5 LED indication and trouble shooting .....     | 39 |
| 8. Operation .....                                | 41 |
| 8.1 Indicator panel .....                         | 41 |
| 8.2 LCD operation flow chart .....                | 42 |

|                                                 |    |
|-------------------------------------------------|----|
| 8.3 LCD Display Icons .....                     | 43 |
| 8.4 System Setup Menu .....                     | 45 |
| 8.5 Basic Settings Menu .....                   | 47 |
| 8.6 Work Mode Settings Menu .....               | 47 |
| 8.7 Battery Settings Menu .....                 | 50 |
| 8.8 Grid Settings Menu .....                    | 52 |
| 8.9 Generator Port Settings Menu .....          | 56 |
| 8.10 Advanced Settings Menu .....               | 58 |
| 8.11 Record Menu .....                          | 61 |
| 8.12 Device Info Setup Menu .....               | 62 |
| 8.13 Factory Setting Menu .....                 | 63 |
| 9. Trouble Shooting .....                       | 64 |
| 10. Maintenance .....                           | 69 |
| 10.1 Power ON the Inverter for first time ..... | 69 |
| 10.2 Power Off the Inverter .....               | 69 |
| 10.3 Removing the Inverter .....                | 69 |
| 10.4 Disposing of the Inverter .....            | 70 |
| 10.5 Routine Maintenance .....                  | 70 |

# 1. About This Manual

This manual describes the product information, installation, electrical connection, commissioning, troubleshooting, and maintenance. Read through this manual before installing and operating the product. All the installers and users have to be familiar with the product features, functions, and safety precautions. This manual is subject to update without notice. For more product details and latest documents, visit our website.

## 1.1 Applicable Model

| Model        | Nominal Output Power | Nominal Output Voltage    |
|--------------|----------------------|---------------------------|
| SSL-8K-P3EU  | 8kW                  | 380 / 400 V a.c., 3W+N+PE |
| SSL-10K-P3EU | 10kW                 | 380 / 400 V a.c., 3W+N+PE |
| SSL-12K-P3EU | 12kW                 | 380 / 400 V a.c., 3W+N+PE |
| SSL-15K-P3EU | 15kW                 | 380 / 400 V a.c., 3W+N+PE |
| SSL-18K-P3EU | 18kW                 | 380 / 400 V a.c., 3W+N+PE |
| SSL-20K-P3EU | 20kW                 | 380 / 400 V a.c., 3W+N+PE |
| SSL-24K-P3EU | 24kW                 | 380 / 400 V a.c., 3W+N+PE |

## 1.2 Target Group

This manual is intended for qualified and knowledgeable electrical technical personnel who are responsible for hybrid inverter installation and commissioning in the energy storage system and electric system.

## 1.3 Symbol Definition

The following types of safety instructions and general information appear in this document as described below:

|  <b>DANGER</b>                                 |  <b>WARNING</b>                                    |  <b>CAUTION</b>                                  |  <b>NOTICE</b> |
|----------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| “Danger” indicates a hazardous situation with a high level of risk that, if not avoided, will result in death or serious injury. | “Warning” indicates a hazardous situation with a medium level of risk that, if not avoided, could result in death or serious injury. | “Caution” indicates a hazardous situation with a low level of risk that, if not avoided, could result in minor or moderate injury. | “Notice” provides some tips and methods to solve product-related problems to save time.            |

# 2. Safety Precaution

Please strictly follow these safety instructions in the user manual during the operation.

## 2.1 General Safety

### **NOTICE**

- The information in this user manual is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions here are for guidance only.
- Before installations, read through the quick installation guide. For additional information, please see the user manual.
- All installations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Use insulating tools and wear personal protective equipment when operating the equipment to ensure personal safety. Wear anti-static gloves, cloths, and wrist strips when touching electron devices to protect the inverter from damage.
- Strictly follow the installation, operation, and configuration instructions in this manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions.

## 2.2 PV String Safety

### DANGER

Connect the DC cables using the delivered PV connectors. The manufacturer shall not be liable for the equipment damage if other connectors or terminals are used.

### WARNING

- Ensure the component frames and the bracket system are securely grounded.
- Ensure the DC cables are connected tightly, securely, and correctly.
- Measure the DC cables with a multimeter to avoid reverse polarity connection. Also, the voltage should be under the permissible range.
- Do not connect one PV string to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.
- The PV modules used with the inverter must have an IEC61730 class A rating.
- When the photovoltaic array is exposed to light, it supplies a d.c. voltage to the inverter.

## 2.3 Inverter Safety

### WARNING

- The voltage and frequency at the connecting point should meet the on-grid requirements.
- Additional protective devices like circuit breakers or fuses are recommended on the AC side. Specification of the protective device should be at least 1.25 times the AC rated output current.
- Make sure that all the groundings are tightly connected. When there are multiple inverters, make sure that all the grounding points on the enclosures are equipotential bonding.
- Off-grid function is not recommended if the PV system is not configured with batteries. Otherwise, the risk in system power usage is beyond the equipment manufacturer's warranty scope.
- It should be taken into account the characteristics of photovoltaic power instability, if the battery is not connected, there is no EPS function.

### DANGER

- All labels and warning marks should be visible after the installation. Do not cover, scrawl, or damage any label on the equipment.
- Warning labels on the inverter are as follows:

|                                                                                     |                                                                                                                                         |                                                                                     |                                                                                                                                                            |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | DANGER High voltage hazard. Disconnect all incoming power and turn off the product before working on it.                                |  | Delayed discharge. Wait 5 minutes after power off until the components are completely discharged.                                                          |
|  | Read through the user manual before working on this device.                                                                             |  | Potential risks exist. Wear proper PPE before any operations.                                                                                              |
|  | High-temperature hazard. Do not touch the product under operation to avoid being burnt.                                                 |  | Grounding point.                                                                                                                                           |
|  | With CE mark & the inverter fulfills the basic requirements of the guideline governing Low-Voltage and electron-magnetic compatibility. |  | Do not dispose of the inverter as household waste. Discard the product in compliance with local laws and regulations, or send it back to the manufacturer. |

## 2.4 Battery Safety

### WARNING

- The battery used with the inverter shall be approved by the inverter manufacturer. The approved battery list can be obtained through the official website.
- Before installations, read through the corresponding battery's User Manual to learn about the product and the precautions. Strictly follow its requirements.
- If the battery discharged completely, please charge it in strict accordance with the corresponding model's User Manual.
- Factors such as: temperature, humidity, weather conditions, etc. may limit the battery's current and affect its load.
- Contact after-sale service immediately if the battery is not able to be started. Otherwise, the battery might be damaged permanently.
- Use the multimeter to measure the DC cable to avoid reverse polarity connection. Also, the voltage should be under the permissible range.
- Do not connect one battery group to several inverters at the same time. Otherwise, it may cause damage to the inverter.

## 2.5 Personal Requirements

### NOTICE

- Personnel who install or maintain the equipment must be strictly trained, learn about safety precautions and correct operations.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, and replace the equipment or parts.

## 2.6 EU Declaration of Conformity

We hereby declares that the inverter without wireless communication modules sold in the European market meets the requirements of the following directives:


- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

### 3. Product Introduction

#### 3.1 Product Features

##### Intended usage

The SSL-8-24K-P3EU series is a leading three-phase low-voltage hybrid inverter designed for residential and small commercial applications, supporting 8~24kW systems. It features up to 415 A charge/discharge current and three battery inputs for versatile energy storage solutions. Built with advanced SiC technology and a robust full aluminum IP66-rated enclosure, it delivers high efficiency, reliability, and durability. The inverter supports a wide voltage input range (154~286V), automatic 50/60Hz frequency adaptation, strong surge resistance, and 150% unbalanced three-phase output.



**Model**

This manual applies to the listed inverters below:

SSL-8K-P3EU    SSL-10K-P3EU    SSL-12K-P3EU    SSL-15K-P3EU  
SSL-18K-P3EU    SSL-20K-P3EU    SSL-24K-P3EU

**Series Code:**

**SN: SXXXXXXXX2401100001**

**Series Code description**

| No. | Referring to             | Code     | Description             |
|-----|--------------------------|----------|-------------------------|
| 1   | Brand name               | S        | Brand                   |
| 2   | Product category         | XXXXXXXX | Inverter model ID       |
| 3   | Production date          | 24       | The year of production  |
| 4   | Production date          | 01       | The month of production |
| 5   | Production date          | 11       | The day of production   |
| 6   | Production serial number | 00001    | serial number           |

## 3.2 Working Mode


The SSL-8K-24K-P3EU Series hybrid inverter has the following work modes based on your configuration and layout conditions.

| Work modes                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Self Use<br>(with PV Power)    | Priority: load>battery>grid<br>The energy produced by the PV system is used to optimize self-consumption. The excess energy is used to charge the batteries, then exported to grid.                                                                                                                                                                                                                                                                                    |
| Self Use<br>(without PV Power) | Priority: load>battery<br>When no PV supplied, battery will discharge for local loads firstly, and grid will supply power when the battery capacity is not enough.                                                                                                                                                                                                                                                                                                     |
| TOU <sup>1</sup> Eco           | This mode can be used to meet users' demand for peak cutting and valley filling and achieve maximum economic benefit in areas with large difference of peak and valley electricity price.<br><b>Peak price:</b> The battery is discharged at full power to sells electricity to the grid at a high price<br><b>Flat price:</b> Run spontaneous self-use mode.<br><b>Valley price:</b> Buy electricity from the grid at a low price to charge the battery at full power |
| Back up only                   | Priority: load>battery<br>When entering this mode, the system will start to charge the battery until it is fully charged and remains fully charged, waiting for the power grid to fail.<br>When the grid is off, system will supply emergency power from PV or battery to supply the home loads .                                                                                                                                                                      |
| Grid Priority                  | Priority: load>grid<br>When the system works in this mode, the electricity generated by the photovoltaic will be preferentially connected to the grid. Users can send requests to the grid at peak times, and in this mode, users can set the end of the battery SOC point.                                                                                                                                                                                            |







Make sure the load powering rating in within the EPS's output rating. Or the inverter will shut down with an 'over load' warning. When an “over load” is appeared, adjust the load power make sure it is with the range of the EPS output, and turn the inverter on. For the nonlinear load, please pay attention to the inrush power make sure it is within the range of the EPS output.

### 3.3 Appearance



| Item | Description     | Item | Description                                            |
|------|-----------------|------|--------------------------------------------------------|
| A    | Power on/off    | H    | Grid                                                   |
| B    | PV switch       | I    | Parallel port                                          |
| C    | BAT             | J    | DRM port                                               |
| D    | PV connector    | K    | BMS port 1                                             |
| E    | Wi-Fi           | L    | BMS port 2<br>(Silkscreen reserved,<br>do not connect) |
| F    | Generator input | M    | Meter port                                             |
| G    | Load            | N    | Function port                                          |



### 3.3.3 Nameplate

The nameplate is for reference only.

| Hybrid Inverter                                                                     |                       |
|-------------------------------------------------------------------------------------|-----------------------|
| Model: SSL-24K-P3EU                                                                 |                       |
| <b>PV Input</b>                                                                     |                       |
| Max. PV Input Voltage                                                               | 1000V d.c             |
| MPPT Voltage Range                                                                  | 150~850V d.c          |
| Max. Input Current                                                                  | 20A d.c*4             |
| Isc PV                                                                              | 30A d.c*4             |
| <b>Battery</b>                                                                      |                       |
| Voltage Range                                                                       | 40~60V d.c            |
| Max.Charge/Discharge Current                                                        | 415A d.c              |
| Battery Type                                                                        | Li-ion/Lead-acid      |
| <b>Grid</b>                                                                         |                       |
| Rated Voltage                                                                       | 380/400V a.c,3W+N+PE  |
| Rated Frequency                                                                     | 50/60Hz               |
| Rated AC Input/Output Current                                                       | 36.4/34.8A a.c        |
| Rated Output Power                                                                  | 24kW                  |
| Power Factor                                                                        | 0.8Leading~0.8Lagging |
| <b>Load</b>                                                                         |                       |
| Rated Voltage                                                                       | 380/400V a.c,3W+N+PE  |
| Rated Frequency                                                                     | 50/60Hz               |
| Rated Output Current                                                                | 36.4/34.8A a.c        |
| Rated Output Power                                                                  | 24kW                  |
| <b>Generator</b>                                                                    |                       |
| GEN Rated Input Current                                                             | 36.4/34.8A a.c        |
| GEN Rated Input Power                                                               | 24kW                  |
| <b>General Parameter</b>                                                            |                       |
| Inverter Topology                                                                   | Non-ioslated          |
| Protective Class                                                                    | I                     |
| Ingress Protection                                                                  | IP66                  |
| Operating Temperature                                                               | -25°C ~ +60°C         |
| Overvoltage Category                                                                | III [AC] , II [DC]    |
| SN                                                                                  |                       |
|  |                       |
| Made in China                                                                       |                       |

### 3.3.4 Features

- Full-load operation from -25°C to +45°C without derating
- Max. 415A charge/discharge, supports three battery inputs
- 2× load surge for 10s, 150% three-phase unbalanced output
- 154V–286V input, 50/60Hz auto-adaptation, built-in SPD
- Up to 8 units parallel, supports AC coupling for retrofit
- High efficiency, lightweight, IP66 protection

### 3.3.5 Specification

| Model                                        | SSL-8K-P3EU               | SSL-10K-P3EU | SSL-12K-P3EU | SSL-15K-P3EU | SSL-18K-P3EU | SSL-20K-P3EU | SSL-24K-P3EU |
|----------------------------------------------|---------------------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Product Type                                 | Hybrid Inverter           |              |              |              |              |              |              |
| Battery                                      |                           |              |              |              |              |              |              |
| Battery type                                 | Li-ion/Lead-acid          |              |              |              |              |              |              |
| Battery voltage range                        | 40-60V d.c                |              |              |              |              |              |              |
| Full power Battery voltage range             | 45-60V d.c                | 45-60V d.c   | 48-60V d.c   | 48-60V d.c   | 51.2-60V d.c | 51.2-60V d.c | 58-60V d.c   |
| Max.charge/discharge Power                   | 8kW /8 kW                 | 10kW /10 kW  | 12kW /12 kW  | 15kW /15 kW  | 18kW /18 kW  | 20kW /20 kW  | 24kW /24 kW  |
| Rated charge/discharge current               | 180A d.c.                 | 220A d.c.    | 250A d.c.    | 315A d.c.    | 350A d.c.    | 390A d.c.    | 415A d.c.    |
| Max. charge/discharge current                | 180A d.c.                 | 220A d.c.    | 250A d.c.    | 315A d.c.    | 350A d.c.    | 390A d.c.    | 415A d.c.    |
| Reverse Connect Protection                   | Yes                       |              |              |              |              |              |              |
| Communication interface                      | CAN/RS485                 |              |              |              |              |              |              |
| Input (PV)                                   |                           |              |              |              |              |              |              |
| Recommended Max. PV module size              | 20~24kW                   | 25~30kW      | 30~36kW      | 37.5~45kW    | 45~54kW      | 50~60kW      | 60~72kW      |
| Max. PV input power                          | 16kW                      | 20kW         | 24kW         | 30kW         | 36kW         | 40kW         | 48kW         |
| Max. operating PV input current (per string) | 4*20A d.c.                |              |              |              |              |              |              |
| Max. Isc PV(per string)                      | 4*30A d.c.                |              |              |              |              |              |              |
| Mmax PV (Max. PV input voltage)              | 1000V d.c                 |              |              |              |              |              |              |
| MPPT Voltage Range                           | 150~850 V d.c.            |              |              |              |              |              |              |
| PV input operating voltage range             | 125~920 V d.c.            |              |              |              |              |              |              |
| Full power MPPT voltage range                | 200-850V d.c              | 250-850V d.c | 300-850V d.c | 375-850V d.c | 450-850V d.c | 500-850V d.c | 600-850V d.c |
| Start-up Voltage                             | 180V d.c                  |              |              |              |              |              |              |
| Number of MPP Trackers                       | 2                         |              |              |              |              |              |              |
| Strings per MPP Tracker                      | 2                         |              |              |              |              |              |              |
| Number of PV input                           | 4                         |              |              |              |              |              |              |
| Max.inverter backfeed current to the array   | 0A                        |              |              |              |              |              |              |
| Grid AC input and AC output                  |                           |              |              |              |              |              |              |
| Grid rated voltage                           | 380 / 400 V a.c., 3W+N+PE |              |              |              |              |              |              |
| Grid rated frequency                         | 50Hz/60Hz                 |              |              |              |              |              |              |
| Grid rated input active power                | 8kW                       | 10kW         | 12kW         | 15kW         | 18kW         | 20kW         | 24kW         |
| Grid rated input apparent power              | 8kVA                      | 10kVA        | 12kVA        | 15kVA        | 18kVA        | 20kVA        | 24kVA        |
| Grid Max. input active power                 | 16kW                      | 20kW         | 24kW         | 30kW         | 36kW         | 40kW         | 40kW         |
| Grid Max. input apparent power               | 16kVA                     | 20kVA        | 24kVA        | 30kVA        | 36kVA        | 40kVA        | 40kVA        |
| Grid rated output active power               | 8kW                       | 10kW         | 12kW         | 15kW         | 18kW         | 20kW         | 24kW         |
| Grid rated output apparent power             | 8kVA                      | 10kVA        | 12kVA        | 15kVA        | 18kVA        | 20kVA        | 24kVA        |
| Grid Max. output active power                | 8kW                       | 10kW         | 12kW         | 15kW         | 18kW         | 20kW         | 24kW         |

|                                                                |                                         |                       |                       |                       |                       |                       |                       |
|----------------------------------------------------------------|-----------------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| Grid Max. output<br>apparent power                             | 8kVA                                    | 10kVA                 | 12kVA                 | 15kVA                 | 18kVA                 | 20kVA                 | 24kVA                 |
| Grid rated input current                                       | 12.1/11.6A a.c                          | 15.2/14.5A a.c        | 18.2/17.4A a.c        | 22.7/21.7A a.c        | 27.3/26.1A a.c        | 30.3/29A a.c          | 36.4/34.8A a.c        |
| Grid Max. input current                                        | 24.2/23.2A a.c                          | 30.4/29A a.c          | 36.4/34.8A a.c        | 45.4/43.4A a.c        | 54.6/52.2A a.c        | 60/58A a.c            | 60/60A a.c            |
| Grid rated output current                                      | 12.1/11.6A a.c                          | 15.2/14.5A a.c        | 18.2/17.4A a.c        | 22.7/21.7A a.c        | 27.3/26.1A a.c        | 30.3/29A a.c          | 36.4/34.8A a.c        |
| Grid Max. output current                                       | 13.5/12.9A a.c                          | 16.8/16.1A a.c        | 20.2/19.3A a.c        | 25.3/24.2A a.c        | 30.3/29A a.c          | 33.7/32.2A a.c        | 40.4/38.6A a.c        |
| Grid power factor                                              | 0.8 leading to 0.8 lagging              |                       |                       |                       |                       |                       |                       |
| Grid input and output<br>Inrush current                        | 150A a.c @10ms                          |                       |                       |                       |                       |                       |                       |
| Max. Grid input fault<br>current                               | 23.2A a.c @10s                          | 29A a.c @10s          | 34.8A a.c @10s        | 43.4A a.c @10s        | 52.2A a.c @10s        | 58A a.c @10s          | 69.6A a.c @10s        |
| Max. Grid input<br>overcurrent protection                      | 400V a.c /100 A a.c                     |                       |                       |                       |                       |                       |                       |
| Grid input Icc (Rated<br>conditional short-circuit<br>current) | 150A a.c                                |                       |                       |                       |                       |                       |                       |
| Grid input Icw (Rated<br>short-time withstand<br>current)      | 150A a.c                                |                       |                       |                       |                       |                       |                       |
| Total Harmonic<br>Distortion(THDi, rated<br>power)             | <3%                                     |                       |                       |                       |                       |                       |                       |
| Generator AC input                                             |                                         |                       |                       |                       |                       |                       |                       |
| Generator rated voltage                                        | 380 / 400 V a.c.,3W+N+PE                |                       |                       |                       |                       |                       |                       |
| Generator rated<br>frequency                                   | 50Hz/60Hz                               |                       |                       |                       |                       |                       |                       |
| Generator rated input<br>active power                          | 8kW                                     | 10kW                  | 12kW                  | 15kW                  | 18kW                  | 20kW                  | 24kW                  |
| Generator rated input<br>apparent power                        | 8kVA                                    | 10kVA                 | 12kVA                 | 15kVA                 | 18kVA                 | 20kVA                 | 24kVA                 |
| Generator rated input<br>current                               | 12.1/11.6A a.c                          | 15.2/14.5A a.c        | 18.2/17.4A a.c        | 22.7/21.7A a.c        | 27.3/26.1A a.c        | 30.3/29A a.c          | 36.4/34.8A a.c        |
| Generator Max. input<br>current                                | 13.5/12.9A a.c                          | 16.8/16.1A a.c        | 20.2/19.3A a.c        | 25.3/24.2A a.c        | 30.3/29A a.c          | 33.7/32.2A a.c        | 40.4/38.6A a.c        |
| EPS output                                                     |                                         |                       |                       |                       |                       |                       |                       |
| EPS rated output Voltage                                       | 380 / 400 V a.c., 3W+N+PE               |                       |                       |                       |                       |                       |                       |
| EPS rated output frequency                                     | 50Hz/60Hz                               |                       |                       |                       |                       |                       |                       |
| EPS rated output active<br>power                               | 8kW                                     | 10kW                  | 12kW                  | 15kW                  | 18kW                  | 20kW                  | 24kW                  |
| EPS rated output apparent<br>power                             | 8kVA                                    | 10kVA                 | 12kVA                 | 15kVA                 | 18kVA                 | 20kVA                 | 24kVA                 |
| EPS Max. output active<br>power                                | 8.8kW                                   | 11kW                  | 13.2kW                | 16.5kW                | 19.8kW                | 22kW                  | 26.4kW                |
| EPS Max. output apparent<br>power                              | 8.8kVA                                  | 11kVA                 | 13.2kVA               | 16.5kVA               | 19.8kVA               | 22kVA                 | 26.4kVA               |
| Eps rated output current                                       | 12.1/11.6A a.c                          | 15.2/14.5A a.c        | 18.2/17.4A a.c        | 22.7/21.7A a.c        | 27.3/26.1A a.c        | 30.3/29A a.c          | 36.4/34.8A a.c        |
| Max. output current                                            | 13.5/12.9A a.c                          | 16.8/16.1A a.c        | 20.2/19.3A a.c        | 25.3/24.2A a.c        | 30.3/29A a.c          | 33.7/32.2A a.c        | 40.4/38.6A a.c        |
| EPS output power factor                                        | 0.8 leading to 0.8 lagging              |                       |                       |                       |                       |                       |                       |
| EPS output peak power                                          | 110% 600s/ 120% 300s/ 150% 60s/200% 10s |                       |                       |                       |                       |                       |                       |
| EPS output Inrush current                                      | 150A a.c @ 10ms                         |                       |                       |                       |                       |                       |                       |
| EPS Max. output fault<br>current                               | 150A a.c @ 10ms                         |                       |                       |                       |                       |                       |                       |
| EPS Max. output<br>overcurrent protection                      | 400V a.c /<br>26A a.c                   | 400V a.c /<br>32A a.c | 400V a.c /<br>38A a.c | 400V a.c /<br>47A a.c | 400V a.c /<br>57A a.c | 400V a.c /<br>64A a.c | 400V a.c /<br>76A a.c |
| Switch Time                                                    | <20ms                                   |                       |                       |                       |                       |                       |                       |
| Total Harmonic<br>Distortion(THDv, linear                      | <3%                                     |                       |                       |                       |                       |                       |                       |

|                                        |                                                                                |             |
|----------------------------------------|--------------------------------------------------------------------------------|-------------|
| Load)                                  |                                                                                |             |
| Compatible with the Generator          | Optional                                                                       |             |
| Efficiency                             |                                                                                |             |
| MPPT Efficiency                        | 99.90%                                                                         |             |
| Euro-efficiency(PV to AC)              | 97.00%                                                                         | 97.20%      |
| Max.efficiency(PV to AC)               | 97.50%                                                                         | 98.00%      |
| Max.efficiency(PV to BAT)              | 94.5%                                                                          | 95.0%       |
| Max.efficiency( AC to BAT / BAT to AC) | 94.0%/93.0%                                                                    | 94.5%/93.5% |
| Standard                               |                                                                                |             |
| Safety                                 | IEC 62109-1/2, IEC 62477-1                                                     |             |
| EMC                                    | IEC 61000-6-1, IEC 61000-6-3                                                   |             |
| Grid-interactive                       | EN 50549-1&-10,UL1741,NRS 097-2-1,ABNT NBR 16149,IEC 61727,IEC 61683,IEC 62116 |             |
| General Parameter                      |                                                                                |             |
| Degree of ingress protection           | IP66                                                                           |             |
| Protection class                       | I                                                                              |             |
| Environment category                   | Outdoor                                                                        |             |
| Wet location classification            | Yes                                                                            |             |
| Pollution degree                       | PD3                                                                            |             |
| Operating altitude                     | 4000 m(>2000 Derating)                                                         |             |
| Operating ambient temperature          | -25 - +60 °C (linearlyderating to 60% when exceed +45 to +60 °C)               |             |
| Operating relative Humidity            | 0-100% (non-condensing)                                                        |             |
| Storage Temperature                    | -25- +60 °C                                                                    |             |
| Storage relative Humidity              | 0-95% (non-condensing)                                                         |             |
| Noise Emission(typical)                | <45 dB                                                                         | <50 dB      |
| Overvoltage Category                   | AC: III, PV: II                                                                |             |
| Electrical supply system               | TN, TT                                                                         |             |
| Dimension (WxHxD)                      | 448*660*265mm                                                                  |             |
| Net Weight                             | 40kg                                                                           | 45kg        |
| Cooling Mode                           | Intelligent Air Cooling                                                        |             |
| Topology                               | Non-isolated                                                                   |             |
| Active anti-islanding method           | Active frequency drift                                                         |             |
| Communication                          | RS485/Wi-Fi/Bluetooth/LAN/CAN/DRM/Meter, Yes/ Yes/ Opt/Opt/ Yes/ Yes/ Opt      |             |
| Display                                | LCD+APP                                                                        |             |

## 3.4 System Diagram

Diagram I : General System




Diagram II : System With Generator




Diagram III : System With Smart Load





Diagram IV : AC Couple System













## 4. Check and Storage

### 4.1 Check Before Receiving

Check the following items before receiving the product.

1. Check the outer packing box for damage, such as holes, cracks, deformation, and others signs of equipment damage. Do not unpack the package and contact the supplier as soon as possible if any damage is found.
2. Check the inverter model. If the inverter model is not what you requested, do not unpack the product and contact the supplier.
3. Check the deliverable for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.

## 4.2 What's in the box?


|                                                                                                                                                                   |                                                                                                                                                 |                                                                                                                                             |                                                                                                                                                             |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Hybrid inverter<br/>x1</p>                                                   |  <p>Wall mounting bracket<br/>x1</p>                           |  <p>Stainless steel anti-collision<br/>bolt M8<br/>x4</p> |  <p>communication<br/>cable<br/>x1</p>                                   |
|  <p>Meter(optional)<br/>x1</p>                                                   |  <p>User<br/>manual<br/>x1</p>                                 |  <p>Wi-Fi-Plug<br/>x1</p>                                 |  <p>Sensor Clamp<br/>x 3</p>                                             |
|  <p>DC+/DC- Plug connectors<br/>including metal terminal<br/>X4</p>             |  <p>Stainless steel mounting<br/>screws HM5<br/>X4</p>        |  <p>PV BATTERY TOOL<br/>X1</p>                           |  <p>Stainless steel mounting<br/>screws M8<br/>8-15k: ×4 16-24k: ×6</p> |
|  <p>Battery connection terminal<br/>(42.5*18.1mm)<br/>8-15k: ×4 16-24k: ×6</p> |  <p>Magnetic ring for BMS<br/>communication cable<br/>x1</p> |  <p>L-type Hexagon wrench<br/>x1</p>                     |                                                                                                                                                             |

## 4.3 Storage

If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements:

1. Do not unpack the outer package or throw the desiccant away.
2. Store the equipment in a clean place. Make sure the temperature and humidity are appropriate and no condensation.
3. The height and direction of the stacking inverters should follow the instructions on the packing box.
4. The inverters must be stacked with caution to prevent them from falling.
5. If the inverter has been long term stored, it should be checked by professionals before being put into use.
6. The storage temperature range is:  $-25^{\circ}\text{C}\sim 60^{\circ}\text{C}$ , and the storage humidity is 0~100%.

7. The box should be suitable for loads more than 75kg.
















## 5. Installation

### 5.1 Installation Requirements


#### Installation Environment Requirements

1. Do not install the equipment in a place near flammable, explosive, or corrosive materials.
2. Do not install the equipment in a place that is easy to touch, especially within children's reach. High temperature exists when the equipment is working. Do not touch the surface to avoid burning.
3. Avoid the water pipes and cables buried in the wall when drilling holes.
4. Install the equipment in a sheltered place to avoid direct sunlight, rain, and snow. Build a sunshade if it is needed.
5. The place to install the equipment shall be well-ventilated for heat radiation and large enough for operations.
6. The equipment with a high ingress protection rating can be installed indoors or outdoors. The temperature and humidity at the installation site should be within the appropriate range.
7. Install the equipment at a height that is convenient for operation and maintenance, electrical connections, and checking indicators and labels.
8. The altitude to install the inverter shall be lower than the maximum working altitude 4000m.
9. The PV modules used with the inverter must have an IEC61730 class A rating.
10. There should be provided an over current protection (such as a breaker rated 100A) before AC input and after EPS output, and make sure that the installation position shall not prevent access to the disconnection means.
11. Please ensure that there is adequate ventilation space for the inverter after installation, refer to the installation diagram below.
12. This inverter does not provide an internal isolated transformer between PV input and Battery / AC output circuits, But a basic insulation is provided between PV input / Battery / AC output circuits and metal enclosure / earth, and reinforced / double insulation between PV input / Battery / AC output and communication circuits (DRM / Meter / Wi-Fi/ RS485)
13. The PV input ratings please refer to the specification table of subclause 3.3.5, and please make sure that PV array should not be grounded.
14. Install the equipment away from electromagnetic interference. If there are radio stations or wireless communication equipment below 30 MHz near the installation location, please install the equipment as follows:
  - Add a multi-turn winding ferrite core at the DC input line or AC output line of the inverter, or add a low-pass EMI filter.
  - The distance between the inverter and the wireless EMI equipment is more than 30m.
15. In lightning-prone areas, please install proper surge protection devices (SPDs) at PV, grid, and load terminals, and ensure reliable grounding. Damage caused by lightning is not covered under warranty-adequate lightning protection is strongly recommended.






## Installation Angle Requirements

- Install the inverter vertically or at a maximum back tilt of 15 degrees.
- Do not install the inverter upside down, forward tilt, back forward tilt, or horizontally.



## Installation Tool Requirements

The following tools are recommended when installing the equipment. Use other auxiliary tools on site if necessary.


|                                                                                     |                                                                                     |                                                                                     |                                                                                      |                                                                                       |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|   |   |   |   |   |
| Goggles                                                                             | Safety shoes                                                                        | Safety gloves                                                                       | Dust mask                                                                            | DC terminal crimping tool                                                             |
|  |  |  |  |  |
| Diagonal pliers                                                                     | Wire stripper                                                                       | Hammer drill                                                                        | Heat gun                                                                             | DC wiring wrench                                                                      |
|  |  |  |  |  |
| Marker                                                                              | Level                                                                               | Heat shrink tube                                                                    | Rubber hammer                                                                        | Vacuum cleaner                                                                        |
|  |  |  |  |                                                                                       |
| Multimeter                                                                          | Cable tie                                                                           | Torque wrench                                                                       | RJ45 crimping pliers                                                                 |                                                                                       |

## 5.2 Inverter Installation

### 5.2.1 Moving the Inverter

#### CAUTION

- The unit is heavy. Do not lift it alone. During lifting procedures ensure that the unit is firmly secured to avoid the risk of accidental tipping or dropping. Parts serving for support or immobilization of unit shall be designed and manufactured so as to minimize the risk of physical injuries and of accidental loosening of fixing. Ensure that the method of lifting will not allow the unit to slip from chains and slings or turn-over or slide from lifting devices.



transport

- Transportation must be carried by specialized person (truck operators, Hook-up personal), equipped with the necessary protection equipment (overalls, safe shoes, protective gloves, helmets, goggles)
- Do not walk or stand beneath or in the proximity of the load. Avoid sudden movements and jolts when unloading and positioning the unit. Internal handling procedures must be conducted with care.
- Do not exert leverage on the components of the machine. If the unit is not balanced, apply ballast. Any protruding parts should not be supported by hand. The inverter should be installed so that the operating panel shall be easily accessible - easy access to the electrical power connection point.
- Accessible for maintenance and repair work. Parts serving for support or immobilization of unit shall be designed and manufactured so as to minimize the risk of physical injuries and accidental loosening of fixings.
- Loading capacity and hardness of the supporting surface, load rating of mounting bracket should be at least four times the weight of the device according to IEC62109-1. And supporting characteristics will be impaired by wear, corrosion, material fatigue or ageing. This should be calculated by inspection of the design data of supporting material and consulting construction engineer.

### 5.2.2 Installing Steps

#### NOTICE

- Avoid the water pipes and cables buried in the wall when drilling holes.
- Wear goggles and a dust mask to prevent the dust from being inhaled or contacting eyes when drilling holes.
- Make sure the inverter is firmly installed in case of falling down.

**Step 1 :** Put the mounting plate on the wall or the support horizontally and mark positions for drilling holes.


**Step 2 :** Drill holes to a depth of 80mm using the hammer drill. The diameter of the drill bit should be 12mm.

**Step 3 :** Secure the mounting plate using the expansion bolts.


**Step 4 :** Install the inverter on the mounting plate.

**Step 5:** Make sure the pin hooks the inverter


**Step 6 :** Install the screw to lock it tight.




Step 1




Step 2




Step 3



Step 4



Step 5



Step 6

## 6. Electrical Connection

### 6.1 Safety Precaution



**DANGER**

- All operations, cables and parts specification during the electrical connection shall be in compliance with local laws and regulations.
- Disconnect the DC switch and the AC output switch of the inverter to power off the inverter at least 5 minutes for the capacitor to be electrically discharged before any electrical connections. Do not work with power on. Otherwise, an electric shock may occur.
- Tie the same type cables together, and place them separately from cables of different types. Do not place the cables entangled or crossed.
- If the cable bears too much tension, the connection may be poor. Reserve a certain length of the cable before connecting it to the inverter cable port.
- When crimping the terminals, ensure that the conductor part of the cable is in full contact with the terminals. Do not crimp the cable jacket with the terminal. Otherwise the inverter may not operate, or its terminal block getting damaged due to heating and other phenomenon because of unreliable connection after operation.




**NOTICE**




- Wear personal protective equipment like safety shoes, safety gloves, and insulating gloves during electrical connections.
- All electrical connections should be performed by qualified professionals.
- Cable colors in this document are for reference only. The cable specifications shall meet local laws and regulations.



## 6.2 Parallel connection notice

If Parallel quantity equal to 4 or bigger than 4, need add a parallel cabinet like follow, for detail can ask sales person.



## 6.3 Connection Port Description




| Wire /Cable(mm²) Size Table                                                         |                                                        |                       |                                                                                                                              |        |
|-------------------------------------------------------------------------------------|--------------------------------------------------------|-----------------------|------------------------------------------------------------------------------------------------------------------------------|--------|
| PV                                                                                  |                                                        | 10AWG~12AWG/4mm²~6mm² |                                                                                                                              |        |
|                                                                                     |                                                        |                       |                                                                                                                              |        |
| Power                                                                               | 8~12k                                                  |                       | 15~20k                                                                                                                       | 24k    |
| Load&Gen                                                                            | 8AWG~10AWG                                             |                       | 6AWG~8AWG                                                                                                                    | 6AWG   |
|                                                                                     | 6mm²~8mm²                                              |                       | 8mm²~10mm²                                                                                                                   | 10mm²  |
|                                                                                     |                                                        |                       |                                                                                                                              |        |
| Ground                                                                              | 10AWG                                                  |                       | 8AWG                                                                                                                         | 6AWG   |
|                                                                                     | 6mm²                                                   |                       | 8mm²                                                                                                                         | 10mm²  |
|                                                                                     |                                                        |                       |                                                                                                                              |        |
| Battery                                                                             | 1/0AWG                                                 |                       | 1/0AWG                                                                                                                       | 1/0AWG |
|                                                                                     | 50mm²                                                  |                       | 50mm²                                                                                                                        | 50mm²  |
|                                                                                     |                                                        |                       |                                                                                                                              |        |
| Connector                                                                           | Description                                            |                       | Recommend cable type                                                                                                         |        |
|  | +: Connect the positive electrode of photovoltaic cell |                       | Industry common outdoor Photovoltaic cable                                                                                   |        |
|                                                                                     | -: Connect the negative electrode of photovoltaic cell |                       |                                                                                                                              |        |
|  | +: Connect the positive electrode of lithium battery   |                       | Outdoor multi-core copper cable                                                                                              |        |
|                                                                                     | -: Connect the negative electrode of lithium battery   |                       |                                                                                                                              |        |
|  | Load(EPS)                                              | L1                    | Outdoor multi-core copper cable<br>L1/L2/L3: Brown/Red/Green or Yellow Wire<br>N: Blue/Black Wire<br>PE: Yellow & Green Wire |        |
|                                                                                     |                                                        | L2                    |                                                                                                                              |        |
|                                                                                     |                                                        | L3                    |                                                                                                                              |        |
|                                                                                     |                                                        | N                     |                                                                                                                              |        |
|                                                                                     |                                                        | PE                    |                                                                                                                              |        |

|                                                                                                   |           |    |                                                                                                                              |
|---------------------------------------------------------------------------------------------------|-----------|----|------------------------------------------------------------------------------------------------------------------------------|
| <div>GRID</div>  | Grid(AC)  | L1 | Outdoor multi-core copper cable<br>L1/L2/L3: Brown/Red/Green or Yellow Wire<br>N: Blue/Black Wire<br>PE: Yellow & Green Wire |
|                                                                                                   |           | L2 |                                                                                                                              |
|                                                                                                   |           | L3 |                                                                                                                              |
|                                                                                                   |           | N  |                                                                                                                              |
|                                                                                                   |           | PE |                                                                                                                              |
| <div>GEN</div>   | Generator | L1 | Outdoor multi-core copper cable<br>L1/L2/L3: Brown/Red/Green or Yellow Wire<br>N: Blue/Black Wire<br>PE: Yellow & Green Wire |
|                                                                                                   |           | L2 |                                                                                                                              |
|                                                                                                   |           | L3 |                                                                                                                              |
|                                                                                                   |           | N  |                                                                                                                              |
|                                                                                                   |           | PE |                                                                                                                              |
| <div>WIFI</div>  | Wi-Fi     |    |                                                                                                                              |

## 6.4 PE Cable Connection

### ⚠ WARNING

- The PE cable connected to the enclosure of the inverter cannot replace the PE cable connected to the AC output port. Both of the two PE cables must be securely connected
- Make sure that all the grounding points on the enclosures are equipotential connected when there are multiple inverters.
- To improve the corrosion resistance of the terminal, it is recommended to apply silica gel or paint on the ground terminal after installing the PE cable.
- Prepare PE cables with the recommended specification:
- Type: Outdoor single-core copper wire
- Cross-sectional area: Please refer to **Wire /Cable(mm<sup>2</sup>) Size Table**



## 6.5 PV Connection

### 6.5.1 PV String Connection

#### DANGER

Confirm the following information before connecting the PV string to the inverter. Otherwise, the inverter may be damaged permanently or even cause fire and cause personal and property losses.

1. Make sure that the max short circuit current and the max input voltage per MPPT are within the permissible range.
2. Make sure that the positive pole of the PV string connects to the PV+ of the inverter. And the negative pole of the PV string connects to the PV - of the inverter.

| Model for EU       | SSL-8-24K-P3EU |
|--------------------|----------------|
| Max. DC Voltage    | 1000V d.c      |
| MPPT Voltage Range | 150V-850V d.c  |


#### WARNING

- 1-Please choose a suitable external DC switch if the inverter does not have a built-in DC switch.
- 2-PV module voltage is very high and within a dangerous voltage range, please comply with the electric safety rules when connecting
- 3-Please **DO NOT** make PV positive or negative to ground.
- 4-PV modules: Please ensure they are the same type, have the same output and specifications, are aligned identically, and are tilted to the same angle. In order to save cable and reduce DC loss, we recommend installing the inverter as near to the PV modules as possible.



#### NOTICE

The DC input cable is prepared by the customer. Recommended specifications:

- Type: the outdoor photovoltaic cable that meets the maximum input voltage of the inverter.
- Conductor cross-sectional area: Please refer to **Wire /Cable(mm<sup>2</sup>) Size Table**



## 6.5.2 PV Wiring

|                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                    |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Step 1: Inspect PV modules</b></p> <ol style="list-style-type: none"> <li>1. Measure the module array voltage with a voltmeter.</li> <li>2. Check the PV+ and PV - from the PV string combiner box correctly.</li> <li>3. Please make sure the impedance between the positive pole and negative pole of PV to ground should be <math>M\Omega</math> level.</li> </ol> |                                                                                                                                                                                                    |
|                                                                                                                                                                                                                                                                                            | <p><b>Step 2: Separate DC Connector</b></p>                                                                                                                                                        |
| <p><b>Step 3: Wiring</b></p> <ol style="list-style-type: none"> <li>1. Connect the 10 AWG wire to the cold crimp terminal.</li> <li>2. Remove 10mm of insulation from the end of the wire.</li> <li>3. Insert the insulator into the pin contact and clamp it with crimping pliers.</li> </ol>                                                                              |                                                                                                                  |
|                                                                                                                                                                                                                                                                                           | <p><b>Step 4: Insert the pin contact through the nut and into the male or female plug, when a "click" is felt or heard, the pin contact assembly is properly seated. Then tighten the nut.</b></p> |
| <p><b>Step 5: Plug the PV connector into the corresponding interface on the inverter.</b></p>                                                                                                                                                                                                                                                                               |                                                                                                                                                                                                    |

## 6.6 EPS and Grid,Generator Connection

### NOTICE

SSL-8-24K-P3EU series inverters are designed for three-phase grid. Voltage range is 380/400 V; frequency is 50/60 Hz. Other technical requests should comply with the requirement of the local public grid.

### WARNING



- Before connecting to the grid, a separate AC breaker must be installed between the inverter and the grid, and also between the backup load and the inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. For the 8/10/12/15/18/20/24kW model, the recommended AC breaker for backup load is 100A. For the 8/10/12/15/18/20/24kW model, the recommended AC breaker for grid is 100A. any load SHOULD NOT be connected with the inverter directly.

- There are three terminal blocks with "Grid" "Load" and "GEN" markings. Please do not misconnect input and output connectors.

Check the grid voltage and compare with the permitted voltage range (refer to technical data).

- Disconnect the circuit-breaker from all the phases and secure against re-connection.
- Please follow below steps to implement Grid, load and Gen port connection:
  - Please refer to local cable type and color for actual installation.
  - Cross-sectional area: Please refer to **Wire /Cable(mm<sup>2</sup>) Size Table**

### 6.6.1 Wiring(as shown in picture)



## 6.7 Battery Connection

### **⚠ DANGER**

- The battery used with the inverter shall be approved by the inverter manufacturer. The approved battery list can be obtained through the official website.
- A short circuit in the battery may cause personal injury. The instantaneous high current caused by a short circuit can release a large amount of energy and may cause a fire.
- Before connecting the battery cable, ensure the inverter and the battery, and downstream&upstream switches, are all disconnected.
- It is forbidden to connect and disconnect the battery cables when the inverter is running. Otherwise it may cause electric shock.
- Do not connect one battery pack to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.
- It is forbidden to connect loads between the inverter and batteries.
- When connecting battery cables, use insulated tools to prevent accidental electric shock or short circuit to the batteries.
- Ensure that the open circuit voltage of the battery is within the permissible range of the inverter.
- Install a DC switch between the inverter and the battery




 **WARNING**

- Please use approved DC cable for battery system.
- Connect the battery cables to the corresponding terminals such BAT+, BAT- and grounding ports correctly. Otherwise it will cause damage to the inverter.
- Ensure that the whole cable cores are inserted into the terminal holes. No part of the cable core can be exposed.
- Ensure that the cables are connected securely. Otherwise it will cause damage to the inverter due to overheat during its operation.
- Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions.
- When replacing batteries, replace with the same type and number of batteries or battery packs.
- CAUTION: Do not dispose of batteries in a fire. The batteries may explode.
- CAUTION: Do not open or damage batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.
- CAUTION: A battery can present a risk of electrical shock and high short-circuit current. The following precautions should be observed when working on batteries:
  - a) Remove watches, rings, or other metal objects.
  - b) Use tools with insulated handles.
  - c) Wear rubber gloves and boots.
  - d) Do not lay tools or metal parts on top of batteries.
  - e) Disconnect charging source prior to connecting or disconnecting battery terminals.
  - f) Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit)

 **NOTICE****Battery breaker**

Before connecting to the battery, install a non-polarized DC circuit breaker to ensure that the inverter can be safely disconnected during maintenance.

## Connection steps:

|                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>• Turn off the PV and battery switch .</li> <li>• Choose 1/0AWG/50mm<sup>2</sup> wire to connect the battery.</li> <li>• Trim 17mm of insulation from the wire end.</li> </ul>                                           |                                                                                                                                                                              |
|                                                                                                                                                                                | <ul style="list-style-type: none"> <li>• Take a <math>\phi</math> 12.5mm copper terminal as shown in the picture.</li> </ul>                                                                                                                                   |
| <ul style="list-style-type: none"> <li>• Insert the cable into the copper terminal port</li> <li>• Crimp pin contact by using a crimping plier. Put the pin contact with striped cable into the corresponding crimping pliers and crimp the contact.</li> </ul> |                                                                                                                                                                              |
|                                                                                                                                                                               | <ul style="list-style-type: none"> <li>• Tighten the cables to the designated position inside the machine, as shown in the figure</li> <li>• The battery copper plate can connect three sets of batteries at the same time, 3*BAT(+) &amp; 3*BAT(-)</li> </ul> |


## 6.8 Communication Cable Installation



### NOTICE

The SSL-8-24K-P3E series inverters are available with multiple communication options such as Wi-Fi, Bluetooth, RS485 and Meter with an external device.


Operating information like output voltage, current, frequency, fault information, etc., can be monitored locally or remotely and cellphone App via these interfaces.

### 6.8.1 Communication Ports





| PIN | Meter        | BMS RJ45           | PARA1/2            | DRM      | <div data-bbox="1077 230 1410 517">  </div> <div data-bbox="1077 555 1410 846">  </div> |
|-----|--------------|--------------------|--------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Meter RS485A | Lead-acid cell NTC | Para Display CAN_H | DRM1/5   |                                                                                                                                                                                                                                                               |
| 2   | Meter RS485B | GND                | Para Display CAN_L | DRM2/6   |                                                                                                                                                                                                                                                               |
| 3   | /            | /                  | /                  | DRM3/7   |                                                                                                                                                                                                                                                               |
| 4   | 5V_VCC       | BMS_CAN1_H         | Para Power CAN1_H  | DRM4/8   |                                                                                                                                                                                                                                                               |
| 5   | FR_ALM_IN    | BMS_CAN1_L         | Para Power CAN1_L  | REFGEN   |                                                                                                                                                                                                                                                               |
| 6   | GND          | GND                | /                  | COM/DRM0 |                                                                                                                                                                                                                                                               |
| 7   | AFCI_485A    | BMS_485A           | Para Power CAN2_H  | +12VS    |                                                                                                                                                                                                                                                               |
| 8   | AFCI_485B    | BMS_485B           | Para Power CAN2_L  | GND      |                                                                                                                                                                                                                                                               |

## 6.9 CT Connection



\*Note: when the reading of the load power on the APP is not correct, please reverse the CT arrow.


## 6.10 Meter Connection




## 6.11 Wiring System for Inverter

This diagram is an example for an application that neutral connects with the PE in a distribution box.

For countries such as Australia, New Zealand, South Africa, etc., please follow local wiring regulations!




This diagram is an example for an application in which neutral is separated from the PE in the distribution box.  
For countries such as China, Germany, the Czech Republic, Italy, etc., please follow local wiring regulations!






## 6.12 Wiring System for Diesel Generator



## 6.13 Three phase parallel connection system



### 1. Only One Master Inverter in a Parallel System

a. In a parallel configuration, the system must have one and only one master inverter to manage overall operations and coordinate communication among the connected inverters.

### 2. CT Sampling Line or Meter Communication Line Must Be Connected to the Master Inverter

a. The CT sampling line or the electric meter communication line must be connected directly to the master inverter, which is designated to handle critical data such as current sampling and power measurement.

b. The master inverter is always assigned as Address 1.

### 3. Slave Inverter Addresses Start from 2 and Are Assigned Sequentially

a. The slave inverters should be assigned addresses starting from 2, with each subsequent inverter receiving the next sequential address (e.g., 2, 3, 4, etc.).

b. Proper address assignment ensures accurate communication and coordination within the system.

## 7. Wi-Fi&BLE stick installation

### 7.1 Indication


A: Circular Connector Interface, Connect to inverter and communication.

B: Green LED, Inverter communication indication.

C: Green LED, Network communication indication.

D: Green LED, Show Wi-Fi data logger operating status.

E: Label, Show SN and password of Wi-Fi data logger.



1. LED glow only when the Wi-Fi&BLE stick is powered on.

2. When the Wi-Fi&BLE stick is powered on, the green LED glows for 3S as a power on indication.




3. The more detail LED indication please refer chapter 8.5 "LED indication and trouble shooting".

Router and ONT should not be connected to the load terminals of the inverter, as this may interfere with remote software updates. These devices can be connected to the Grid side to ensure uninterrupted network service.

## 7.2 Install the Wi-Fi&BLE stick

Follow the installation steps!

|                                |                                     |
|--------------------------------|-------------------------------------|
| 1.Remove the waterproof cover. | 2.Aligning groove.                  |
| 3.Plug in Wi-Fi module.        | 4.Revolve to lock the Wi-Fi module. |



## 7.3 Web/APP

If you are an household user, please scan QR code below to download SOLARMAN Smart APP. Or you can log in to <https://home.solarmanpv.com>



SOLARMAN Smart


## 7.4 Wi-Fi Connection

### 7.4.1 Log in to your account


Step 1: Select language

Step 2: Create an account

Step 3: Enter your account and password to log in



## 7.4.2 Create a plant




Step 1: Click "Add Now" to create your plant

The 'Plant Details' form is divided into two sections: 'Basic Info' and 'System Info'. The 'Basic Info' section includes fields for Plant Name (Demo plant-Commercial), Plant Loc (Zhwjiang yuyao), Time Zone ((UTC+08:00)Beijing,Chongqing,HongKong,Urumqi), Creation Date (2019-05-04), and Founder (Clavin). The 'System Info' section includes fields for Plant Type (Residential Rooftop), System Type (All on Grid), and Installed Capacity (kWp) (18350). A blue 'Finish' button is at the bottom.

Step 2: Fill in plant basic information and other information here. Then click "Finish" option

## 7.4.3 Add a Logger




Step 1: Click the "+" icon in the upper-right corner, then click "Add a device"

The 'Add a Logger' screen has a text input field for 'SN' with the placeholder 'Please enter device SN' and a barcode scanner icon. Below the input field, it says 'Cannot Find SN/Barcode?'. A blue 'Add target device' button is at the bottom.

Method 1: Enter logger SN manually.  
Method 2: Click the icon in the right and scan to enter logger SN.



**NOTE:** You can find logger SN in the external packaging or on the logger body.

#### 7.4.4 Network Configuration



Step 1: Click "Go to Configure" to set the network (Please make sure Bluetooth and Wi-Fi are ON.)

Step 2: Choose Wi-Fi network and enter password to log in.



Step 3: Please wait for a few minute. Then click "Done" and view plant data.

#### NOTICE

5G Wi-Fi is not supported

## 7.5 LED indication and trouble shooting

### 7.5.1 Check Indicator light

| Lights                                                                            | Implication                 | Status Description(All lights are single green lights.)                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Communication with router   | 1.Light off: Connection to the router failed.<br>2.On 1s/Off 1s(Slow flash): Connection to the router succeeded.<br>3.Light keeps on: Connection to the server succeeded.<br>4.On 100ms/Off 100ms(Fast flash): Distributing network fast. |
|  | Communication with inverter | 1.Light keeps on: Logger connected to the inverter.<br>2.Light off: Connection to the inverter failed.<br>3.On 1s/Off 1s(Slow flash): Communicating with inverter.                                                                        |
|  | Logger running status       | 1.Light off: Running abnormally.<br>2.On 1s/Off 1s (Slow flash): Running normally.<br>3.On 100ms/Off 100ms(Fast flash): Restore factory settings.                                                                                         |

### 7.5.2 Abnormal State Processing

If the data on platform is abnormal when the stick logger is running, according to the status of indicator lights to complete a simple troubleshooting. If it still can not be resolved or indicator lights status do not show in the table below, please contact Customer Support.

Note: Please using the following table query after power-on for 2mins at least.


The normal operation status of the stick logger, when router connected to the network normally:

- 1.Connection to the server succeeded: NET light keeps on after the logger powered on.
- 2.Logger running normally: READY light flashes.
- 3.Connection to the inverter succeeded: COM light keeps on.

| NET<br> | COM<br> | READY<br> | Fault Description                                                                                  | Fault Cause                                                                                                                      | Solution                                                                                                                                                                                                                                          |
|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Any state                                                                                | OFF                                                                                      | Slow flash                                                                                 | Communicate with inverter abnormally                                                               | 1.Connection between stick logger and inverter loosen.<br>2.Inverter does not match with stick logger's communication rate.      | 1.Check the connection between stick logger and inverter. Remove the stick logger and install again.<br>2.Check inverter's communication rate to see if it matches with stick logger's.<br>3.Long press Reset button for 5s, reboot stick logger. |
| OFF                                                                                      | ON                                                                                       | Slow flash                                                                                 | Connection between logger and router abnormal                                                      | 1.Stick logger does not have a network.<br>2.Router Wi-Fi signal strength weak.                                                  | 1.Check if the wireless network configured.<br>2.Enhance router Wi-Fi signal strength.                                                                                                                                                            |
| Slow flash                                                                               | ON                                                                                       | Slow flash                                                                                 | Connection between logger and router normal, connection between logger and remote server abnormal. | 1.Router networking abnormal.<br>2.The server point of logger is modified.<br>3.Network limitation, server cannot be connected.  | 1.Check if the router has access to the network.<br>2.Check the router's setting, if the connection is limited.<br>3.Contact our customer service.                                                                                                |
| OFF                                                                                      | OFF                                                                                      | OFF                                                                                        | Power supply abnormal                                                                              | 1.Connection between stick logger and inverter loosen or abnormal.<br>2.Inverter power insufficient.<br>3.Stick Logger abnormal. | 1.Check the connection, remove the stick logger and install again.<br>2.Check inverter output power.<br>3.Contact our customer service.                                                                                                           |
| Fast flash                                                                               | Any state                                                                                | Any state                                                                                  | Networking status                                                                                  | Normal                                                                                                                           | 1.Exit automatically after 2mins.<br>2.Long press Reset button for 5s, reboot stick logger.<br>3.Long press Reset button for 10s, restore factory settings.                                                                                       |
| Any state                                                                                | Any state                                                                                | Fast flash                                                                                 | Restore factory settings                                                                           | Normal                                                                                                                           | 1. Exit automatically after 1min.<br>2. Long press Reset button for 5s, reboot stick/logger.<br>3. Long press Reset button for 10s, restore factory settings.                                                                                     |


## 8. Operation

### 8.1 Indicator panel



| Name          | Object | Function                                                |
|---------------|--------|---------------------------------------------------------|
| Indicator LED | A      | Green : ON, The inverter is running ; Flash is Standby. |
|               | B      | Blue : ON, Communication with BMS normal.               |
|               | C      | Yellow : ON, The inverter is in EPS mode.               |
|               | D      | Red : The inverter is in fault mode.                    |
|               | E      | UP:To go to previous selection                          |
|               | F      | DOWN:To go to next selection                            |
|               | G      | ENTER:To confirm the selection                          |
|               | H      | ESC:To exit setting mode                                |


## 8.2 LCD operation flow chart



## 8.3 LCD Display Icons

### 8.3.1 Main Screen

The LCD is touchscreen, below screen shows the overall information of the inverter.



#### 2. Inverter Status and Operating Mode

##### 2.1 Inverter Power Status

The icon in the center represents the inverter unit. Its power status is clearly shown as ON or OFF.

##### 2.2 Current Operating Mode Display

The active system mode is shown above the inverter icon.

Possible modes include: TOU ECO, Self-Use, Backup, etc.

This helps users understand how the system is currently

#### 1. System Information Display

##### 1.1 Date and Time

At the top of the screen displays the current system date and time.

##### 1.2 Warning Icon (!)

A red '!' mark indicates a system fault or abnormal condition.

Clicking the icon opens the fault detail page, where users can check the alarm messages and fault codes.

Follow the on-screen guidance or troubleshooting manual to resolve issues.

##### 1.3 Settings Icon (Gear)

Click to access the system settings menu.

Includes configuration options such as operation mode, battery parameters, grid settings, etc.

#### 3. Real-Time Energy Device Overview

The four blue icons visually represent the status and power of key energy components. Each icon is interactive:

##### 3.1 Top Left--PV

Displays real-time solar generation power.

Click to view detailed PV status.

##### 3.2 Top Right--Grid

Shows grid import power.

Click to view grid connection information.

##### 3.3 Bottom Left--Battery

Displays current battery state of charge and charge/discharge power.

Click to view battery details.

##### 3.4 Bottom Right--Load

Shows real-time load consumption.

Click to access detailed load information.

#### 4. Energy Flow and Connection Indicators

##### 4.1 Arrow Indicators

Arrows illustrate real-time energy flow paths.

The direction indicates the power flow direction (e.g., from PV to Load).

##### 4.2 Red "X" Icons

Indicate that a path or device is not connected or inactive.

Examples include: battery not installed, grid offline, etc.

-PV power and Load power always keep positive.

-Grid power negative means get from grid, positive means sell to grid.

-Battery power negative means charge, positive means discharge.

### 8.3.2 PV Information Page Overview

| Solar                            |              |               |
|----------------------------------|--------------|---------------|
| PV1-V: 0.0 V                     | PV1-I: 0.0 A | PV1-P: 0.0 kW |
| PV2-V: 0.0 V                     | PV2-I: 0.0 A | PV2-P: 0.0 kW |
| PV3-V: 0.0 V                     | PV3-I: 0.0 A | PV3-P: 0.0 kW |
| PV4-V: 0.0 V                     | PV4-I: 0.0 A | PV4-P: 0.0 kW |
| Power: 0.0 kW                    |              |               |
| Today: 0.0 kWh    Total: 0.0 kWh |              |               |



(Subject to variation depending on project configuration)

When the PV icon on the main interface is clicked, the system navigates to the PV information page. Here, PV1 to PV4 display the voltage, current, and power data for each of the four PV input channels. Below these readings, users can view the total current PV power, the energy generated today, and the historical cumulative generation. Page navigation arrows on the side of the screen allow users to scroll through additional PV data pages

### 8.3.3 Grid Information Page Overview

| Grid        |                |                |
|-------------|----------------|----------------|
| Fault       | Power: 0.0 kW  | Freq: 0.0 Hz   |
| L1-V: 0.0 V | L1-I: 0.0 A    | L1-P: 0.0 kW   |
| L2-V: 0.0 V | L2-I: 0.0 A    | L2-P: 0.0 kW   |
| L3-V: 0.0 V | L3-I: 0.0 A    | L3-P: 0.0 kW   |
| BUY         | Today: 0.0 kWh | Total: 0.0 kWh |
| SELL        | Today: 0.0 kWh | Total: 0.0 kWh |



The Status field indicates the operating condition of the inverter; in this example, the current status is "Fault."

The Power field displays the total grid power.

Freq refers to the present grid frequency.

L1, L2, and L3 represent the three AC phases (R, S, T), each showing their respective voltage, current, and power values.

At the bottom of the page, the energy purchased from the grid is displayed, including both the daily purchased energy and cumulative purchased energy. (Note: These fields may vary depending on the specific project configuration.)

### 8.3.4 Battery Information Page Overview

| Battery                |                |       |
|------------------------|----------------|-------|
| Battery 1: No Ch&DisCh | Ch limit A:    | 0.0 A |
| Bat-V: 0.0 V           | Disch limit A: | 0.0 A |
| Bat-I: 0.0 A           | Ch limit V:    | 0.0 V |
| Bat-P: 0 W             | Disch limit V: | 0.0 V |
| temp: 0.0 C            |                |       |
| SOC: 0 %               |                |       |
| Ch rquest: No          |                |       |
| Ch limit: No           |                |       |
| Disch limit: No        |                |       |



This page displays the operating information of Battery (subject to variation depending on the project configuration).

Key parameters include the current battery status, voltage, current, power, temperature, and State of Charge (SOC).

8.3.5 Load Information Page Overview



Load

EPS Load: 0.0 kW

Home Load: 0.0 kW

Smart Load: 0.0 kW

Total Load: 0.0 kW

Today: 0.0 kWh

Total: 0.0 kWh

EPS-RU: 0.0 V

EPS-SU: 0.0 V

EPS-TU: 0.0 V

EPS-RI: 0.0 A

EPS-SI: 0.0 A

EPS-TI: 0.0 A

Pwr: 0.0 kW

Pwr: 0.0 kW

Pwr: 0.0 kW







(Subject to variation depending on the project configuration)

This page includes readings for EPS load power, household load power, smart load power, and the total load power.

Below these values, the page also displays the voltage, current, and power for the three AC phases: R, S, and T (corresponding to L1, L2, and L3).

8.4 System Setup Menu

System Settings Page (Standard User Access)

This is the settings page available under standard user permissions.

System Setup

Work Mode

Basic Setting

Record

Device Info

To enter basic settings mode, click the icon  in the upper-left corner and enter the password **0000**.

|   |   |   |        |
|---|---|---|--------|
|   |   |   | Range  |
| 7 | 8 | 9 |        |
| 4 | 5 | 6 | DEL    |
| 1 | 2 | 3 | CANCEL |
|   | 0 | . | OK     |



System Setup

Work Mode

Battery Setting

Grid Setting

Gen Port Use

Advanced Func

Factory Setting

Basic Setting

Record

Device Info

Quick Install

Range

7

8

9

4

5

6

DEL

1

2

3

CANCEL

0

.

OK

To enter advanced settings mode, click the icon  in the upper-left corner and enter the password 7777. Once verified, the system will open the Advanced Settings Page, where users can access additional configuration options not available under standard permissions.

## 8.5 Basic Settings Menu

 Basic Setting

Time Setting

2023

-

11

-

10

12

:

8

:

58

LCD Light

100 %

Beep

No



Auto Dim Time

600 s

Language

English



### -Time Setting:

Set the system's date and time, including year, month, day, hour, and minute.

### -LCD Light:

Adjust the screen brightness level.

### -Beep:

Enable or disable the buzzer.

Enabled by default; the buzzer will sound upon touch or key press.

### -Auto Dim Time:

Set the duration before the screen automatically dims or turns off.

### -Language:

Select the system display language.

## 8.6 Work Mode Settings Menu

### Work Mode Settings-Page 1

 Work Mode 1/3

Max Solar Power

0.0 kW

Zero Export to Grid

No



Max Sell Power

0.0 kW

Zero-export Power

0.0 kW



Energy pattern

Load First



### -Max Solar Power:

Sets the maximum PV input power.

### Zero Export to Grid:

When enabled, the inverter limits the amount of power exported to the grid.

The actual export limit is defined by the Zero-export Power setting.

### -Zero-export Power:

Specifies the inverter's export power limit to the grid.

This setting takes effect only when Zero Export to Grid is enabled.

### -Max Sell Power:

Sets the maximum power that can be exported to the grid.

### -Energy Pattern:

Defines the system's energy priority strategy. Currently, only **Load First** mode is supported.

### -Load First:

PV power is used first to supply the load.

Any surplus PV energy is then used to charge the battery. If PV is insufficient, the grid will supply the load.

## Work Mode Settings-Page 2



### Work Mode 2/3

|                       |         |
|-----------------------|---------|
| Power On/Off          | OFF     |
| Auto Power On         | No      |
| Work Mode             | TOU ECO |
| On-Grid Bat Stop SOC  | 10 %    |
| Off-Grid Bat Stop SOC | 10 %    |
| Charge Max Soc        | 100 %   |



#### -Power On/Off:

Manually switches the inverter ON or OFF.

#### -Auto Power On:

Enables automatic startup and shutdown.

When enabled,the inverter will power on automatically.

#### -Work Mode:

Sets the system's working mode.Available options include:

**Self-USE,TOU ECO,Backup Power,and Grid Priority.**

#### -On-Grid Bat Stop SOC:

When the inverter is connected to the grid:

Battery is allowed to discharge if SOC 10%.

If battery SOC drops below(Restart SOC-3),the inverter will trigger forced charging to raise SOC back to 10%.

#### -Off-Grid Bat Stop SOC:

When the inverter is off-grid (not connected to the utility):

Battery is allowed to discharge if SOC 10%.

#### -Charge Max SOC:

Sets the maximum battery SOC for charging.

Once this limit is reached,charging will stop automatically.

## Work Mode Settings-Page 3(TOU Mode Settings)

 Work Mode--TOU 3/3

|   | Time  |       | Type     | Curr | SOC |                                                                                                                                                                                                                                                             |
|---|-------|-------|----------|------|-----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| - | 00:00 | 12:30 | Disch    | 0 A  | 0 V |                                                                                                                                                                            |
| + | 12:30 | 23:59 | Self-Use | 0 A  | 0 V | <br><br> |

To enable TOU scheduling, the Work Mode on **Work Mode Settings – Page 2** must be set to **TOU ECO**. Only then will the time-based configuration become effective.

**-Time:Defines the time slots used for energy management.**

The full 24-hour day must be divided into continuous,non-overlapping periods.Each time slot includes a start time and an end time.Up to 6 time slots can be added by clicking the "+"icon.

**-Type:Defines the behavior of the system during the time slot:**

Discharge:Battery discharges according to the specified parameters.

Charge:Battery charges using PV or grid power.

Self-Use:Prioritizes self-consumption from PV.

**-Curr:Sets the maximum charging or discharging current for the battery.**

**-SoC:Target SOC value for the battery during the time slot.**

## Example Schedule:

| Time Period   | Priority Type | Zero Export Disabled                                                                                                                                                                                            | Zero Export Enabled                                                                                                                                  |
|---------------|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| 00:00 – 12:30 | Discharge     | <ul style="list-style-type: none"> <li>- Battery discharges if SOC &gt; 20% (up to 50A limit)</li> <li>- Excess PV is exported to the grid</li> </ul>                                                           | <ul style="list-style-type: none"> <li>- Same discharge behavior</li> <li>- Excess PV charges battery to avoid waste</li> </ul>                      |
| 12:30 – 16:30 | Self Use      | <ul style="list-style-type: none"> <li>- Battery discharges if SOC &gt; 40% when PV cannot meet load</li> <li>- Battery charges if SOC &lt; 36% using PV or grid</li> <li>- Remaining PV is exported</li> </ul> | <ul style="list-style-type: none"> <li>- Same behavior</li> <li>- No export allowed: Excess PV not used for load or charging is curtailed</li> </ul> |
| 16:30 – 23:59 | Charge        | <ul style="list-style-type: none"> <li>- Battery charges if SOC &lt; 90% using PV + grid (up to 30A)</li> <li>- Excess PV is exported</li> </ul>                                                                | <ul style="list-style-type: none"> <li>- Same charging behavior</li> <li>- No export allowed: Any excess PV after charging is curtailed</li> </ul>   |

## 8.7 Battery Settings Menu

### Battery Setting1 – Page 1



Bat Setting 1/2

|                 |          |               |         |
|-----------------|----------|---------------|---------|
| Bat Company     | PYLON HV |               |         |
| Max A Charge    | 0 A      | Bat1 Type     | Lithium |
| Max A Disch     | 0 A      | Activate Batt | No      |
| Max Power Ch    | 0 kW     | Com Type      | 1-CAN   |
| Max Power Disch | 0 kW     | Grid Charge   | No      |
| Shared Bat      | No       | Disch To Grid | No      |

#### 1.-Max A Charge / Max A Disch:

Set the **maximum battery charging current** and **maximum battery discharging current**, respectively.

#### -Max Power Ch / Max Power Disch:

Set the **maximum charging power** and **maximum discharging power** for the battery.

#### -Grid Charge:

Enables or disables battery charging from the utility grid.

#### 2.-Parallel Bat & Bat2:

For inverter models with two battery ports, enabling this function allows a single battery to be connected to both **Battery Port 1** and **Battery Port 2** simultaneously.

In this case, the battery communication cable should be connected to the inverter's **BMS1 port**.

#### -Batt1 Type:

Select the battery type. Available options include: **Lithium**, **Lead-acid**, **DC Source**, and **No Battery**.

#### -Activate Batt:

Manually triggers battery activation or wake-up.

#### 3.-Com Type:

Select the battery communication protocol: **CAN** or **RS485**

#### -Company:

Select the battery manufacturer. The system will automatically match the correct communication protocol based on the selected brand.

## Battery1 Setting2 – Page 2



Bat Setting 2/2

|                |       |                       |      |                                                                                                                                                                                                                                                                                                                                                              |
|----------------|-------|-----------------------|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Float V        | 0.0 V | Ch Ratio              | 0.00 | <br><br><br><br><br><br> |
| Equalization V | 0.0 V | TEMPCO(mV/<br>C/Cell) | 0    |                                                                                                                                                                                                                                                                                                                                                              |
| Shutdown       | 0.0 V | Parallel Num          | 0    |                                                                                                                                                                                                                                                                                                                                                              |
| High Batt      | 0.0 V | Batt Capacity         | 0 Ah |                                                                                                                                                                                                                                                                                                                                                              |
| Low Batt       | 0.0 V |                       |      |                                                                                                                                                                                                                                                                                                                                                              |

### Float V:

Sets the **battery float charging voltage**.

### Ch Ratio:

Sets the **charging C-rate** (charging ratio), applicable **only to lead-acid batteries**.

### Equalization V:

Sets the **equalization charging voltage**.

### TEMPCO:

Battery **temperature compensation coefficient**, applicable **only to lead-acid batteries**.

### Shutdown:

Sets the **battery discharge cutoff voltage** for protection.

### Parallel Num:

Sets the **number of parallel-connected battery groups**.  
This setting is required **only for lead-acid batteries** used in multiple parallel clusters.

### High Batt / Low Batt:

Define the **battery port over-voltage** and **under-voltage protection thresholds**, respectively.

### Batt Capacity:

Set the **battery capacity**, applicable **only to lead-acid batteries**.

## Recommended battery settings

| Battery Type | Absorption Stage                  | Float Stage   | Equalization Voltage<br>(every 30 days 3hr) |
|--------------|-----------------------------------|---------------|---------------------------------------------|
| AGM(or PCC)  | 14.2V (57.6V)                     | 13.4V (53.6V) | 14.2V (57.6V)                               |
| Gel          | 14.1V (56.4V)                     | 13.5V (54.0V) |                                             |
| Wet          | 14.7V (59.0V)                     | 13.7V (55.0V) | 14.7V (59.0V)                               |
| Lithium      | Follow its BMS voltage parameters |               |                                             |

## 8.8 Grid Settings Menu

### Grid Settings – Page 1

 Grid Code Selection 1/4

|                   |               |               |        |                                                                                                                                                                                                                                                                                                                                                  |
|-------------------|---------------|---------------|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Grid Mode         | Italy CEIO-21 |               |        | <br><br><br> |
| Grid Volt         | 220V          | Grid Sensor   | None   |                                                                                                                                                                                                                                                                                                                                                  |
| Grid Freq         | 50Hz          | CT Ratio      | 0      |                                                                                                                                                                                                                                                                                                                                                  |
| Zero Export       | No            | Meter Addr    | 1      |                                                                                                                                                                                                                                                                                                                                                  |
| Zero Export Power | 0.0 kW        | Meter Select  | CHNT   |                                                                                                                                                                                                                                                                                                                                                  |
| Max Sell Power    | 0.0 kW        | Max Buy Power | 0.0 kW |                                                                                                                                                                                                                                                                                                                                                  |

Grid Mode: Select the national grid standard according to the installation region (e.g., Italy-CEIO-21, Spain UNE217002).

Grid Sensor: Configuration of the grid-side current sampling method. Options include:

None: Inverter samples current internally at the grid port.

CT: External current transformer (CT) is used for sampling.

Meter: External smart meter connected via RS485 for grid data acquisition.

Grid Volt: Set the nominal grid voltage according to the country standard.

Grid Freq: Set the nominal grid frequency based on the local grid specification.

CT Ratio: Set the CT transformation ratio.

Zero Export: When enabled, the inverter will limit the power exported to the grid.

The limit is defined by the Zero-export Power setting.

Zero-export Power: Sets the maximum inverter export power. This is only effective when Zero Export is enabled.

Meter Addr: Set the RS485 address of the external energy meter.

Meter Select: Select the meter manufacturer. Please ensure the selected model matches the actual hardware.

Max Sell Power: Sets the maximum allowed output power exported to the grid.

Max Buy Power: Sets the maximum allowed input power drawn from the grid to the inverter.

## Grid Settings – Page 2



### Grid Connect 2/4

|                        |                                   |             |                                 |  |
|------------------------|-----------------------------------|-------------|---------------------------------|--|
| Out Active Power       | <input type="text" value="0 kW"/> | L/HVRT Mode | <input type="text" value="No"/> |  |
| Normal Ramp rate       | <input type="text" value="0 s"/>  | L/HPRT Mode | <input type="text" value="No"/> |  |
| Normal Connection Time | <input type="text" value="0 s"/>  | P-V Mode    | <input type="text" value="No"/> |  |
| Reconnect Ramp rate    | <input type="text" value="0 s"/>  | P-P Mode    | <input type="text" value="No"/> |  |
| Reconnection Time      | <input type="text" value="0 s"/>  | Q-V Mode    | <input type="text" value="No"/> |  |
| PF                     | <input type="text" value="0.0"/>  | SPF Mode    | <input type="text" value="No"/> |  |

**Reserved:**This function is reserved.It is not recommended.Please inform the manufacturer/installer before setting up

Out Active Power:

Sets the maximum apparent power output to the grid.

Normal Ramp Rate:

Sets the power ramp-up time after inverter startup.

Normal Connection Time:

Sets the time delay before the inverter injects active power to the grid after startup.

Reconnect Ramp Rate:

Sets the ramp-up time for active power after fault recovery.

Reconnection Time:

Sets the reconnection delay time after a fault is cleared.

## Grid Settings-Page 3



### Grid Protection1 3/4

|                  |                                     |                 |                                     |  |
|------------------|-------------------------------------|-----------------|-------------------------------------|--|
| High volt 1      | <input type="text" value="0.0 %"/>  | Low volt 1      | <input type="text" value="0.0 %"/>  |  |
| High volt 2      | <input type="text" value="0.0 %"/>  | Low volt 2      | <input type="text" value="0.0 %"/>  |  |
|                  |                                     | Low volt 3      | <input type="text" value="0.0 %"/>  |  |
| High volt time 1 | <input type="text" value="0.00 s"/> | Low volt time 1 | <input type="text" value="0.00 s"/> |  |
| High volt time 2 | <input type="text" value="0.00 s"/> | Low volt time 2 | <input type="text" value="0.00 s"/> |  |
|                  |                                     | Low volt time 3 | <input type="text" value="0.00 s"/> |  |
| High volt recv   | <input type="text" value="0.0 %"/>  | Low volt recv   | <input type="text" value="0.0 %"/>  |  |

**Reserved:**This function is reserved.It is not recommended.  
Please inform the manufacturer/installer before setting up

High Volt 1/High Volt 2:Level 1 and Level 2 overvoltage protection thresholds (as a percentage of nominal voltage).

High Volt Time 1/High Volt Time 2:Time delays for triggering Level 1 and Level 2 overvoltage protection.

High Volt Recv:Grid overvoltage recovery threshold.

Low Volt 1 Low Volt 2:Level1 and Level 2 undervoltage protection thresholds,also defined as percentages of the nominal voltage.

#### Example

To adjust the acceptable voltage range of the inverter for grid connection:

Simply configure High Volt 1 and Low Volt 1 values.

If the nominal voltage is 230V:

High Volt 1 at 120%-Overvoltage point 276V

Low Volt 1 at 80%-Undervoltage point 184V

If the nominal voltage is 220V:

High Volt 1 at 120%-Overvoltage point 264V

Low Volt 1 at 80%-Undervoltage point 176V

## Grid Settings-Page 4

Grid Protection2 4/4

|                  |        |                 |        |  |
|------------------|--------|-----------------|--------|--|
| High freq 1      | 0.0 Hz | Low freq 1      | 0.0 Hz |  |
| High freq 2      | 0.0 Hz | Low freq 2      | 0.0 Hz |  |
| High freq time 1 | 0.00 s | Low freq time 1 | 0.00 s |  |
| High freq time 2 | 0.00 s | Low freq time 2 | 0.00 s |  |
|                  |        |                 |        |  |
| High freq recv   | 0.0 Hz | Low freq recv   | 0.0 Hz |  |

**Reserved: This function is reserved. It is not recommended.**

**Please inform the manufacturer/installer before setting up**

High Freq 1 and High Freq 2 refer to the first- and second-level over-frequency protection thresholds (in Hz). These values are typically based on the system's nominal frequency (e.g., 50Hz or 60Hz).

High Freq Time 1 and High Freq Time 2 define the delay time before triggering protection actions when the grid frequency exceeds the corresponding threshold.

High freq recv: The recovery point frequency value of the power grid overfrequency protection. When the frequency recovers from too high to below this value, the system will allow reconnection to the grid or resume operation.

Low Freq 1 and Low Freq 2 represent the first- and second-level under-frequency protection thresholds. If the frequency falls below these values, protection will be triggered accordingly.

Low Freq Time 1 and Low Freq Time 2 set the delay durations before activating under-frequency protection once the frequency drops below the set limits.

Low Freq Recv: The recovery threshold for under-frequency protection. The system will reconnect or resume operation when the grid frequency rises above this value.

Example:

If the system nominal frequency is 50Hz, and the settings are as follows:

High Freq 1 = 52Hz, Low Freq 1 = 47Hz

The system will trigger first-level protection when the frequency goes above 52Hz or below 47Hz, based on the defined time delays.

High Freq 2 = 53Hz, Low Freq 2 = 46Hz

More severe deviations will activate second-level protection mechanisms. High Freq 1 and High Freq 2 refer to the first- and second-level over-frequency protection thresholds (in Hz). These values are typically based on the system's nominal frequency (e.g., 50Hz or 60Hz).

## 8.9 Generator Port Settings Menu

### Gen Port Function

Select the functional mode of the generator port. Available options:



#### Generator Setting 1/2

Gen Port Function

Gen

Gen Warm Time

8 s

Start Soc/V

180.1 V

Gen Max Ch Pwr

60 kW

Stop Soc/V

450.0 V

Max Run Time

600 min

Start Time

08:00

Cooling Time

10 min

End Time

16:00

Gen Force

No

↓

↺

✕

✓

None:No function assigned.This is the default setting.

Generator:The port is used as an input for generator power.Once the generator starts,its power is used to charge the battery.

Smart Load:The port is used as a dedicated load output,with user-defined working conditions for smart load control.

**When Gen Port Function is set to Generator,** the following parameters become effective:

Gen Warm Time:  
Generator warm-up time. After the inverter sends the start signal, it waits for this duration before accepting generator input.

Start SOC / Stop SOC:  
Battery SOC thresholds for starting and stopping the generator automatically.

Gen Rated Power:  
Maximum power output of the generator.

Max Run Time:  
Maximum continuous run time for the generator. Applies when the inverter is automatically controlling the generator.

Cooling Time:  
Generator cooldown period after stopping. Applies to inverter-controlled generator operation.

Gen Force:  
Force Start Generator function. Should be enabled during the first-time connection of a generator to ensure recognition and activation.

## Smart Load Configuration

This configuration page becomes effective only when Gen Port Function is set to Smart Load.



### Smart Load 2/2

|                    |                                    |                                                                                                                                                                                                                                                                                                                                                  |
|--------------------|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Stop Output Soc    | <input type="text" value="0 %"/>   | <br><br><br> |
| Stop Output Volt   | <input type="text" value="0 V"/>   |                                                                                                                                                                                                                                                                                                                                                  |
| Control Start Time | <input type="text" value="00:00"/> |                                                                                                                                                                                                                                                                                                                                                  |
| Control End Time   | <input type="text" value="00:00"/> |                                                                                                                                                                                                                                                                                                                                                  |

Stop Output SOC:  
When the battery SOC drops to this threshold, the smart load output will automatically disconnect.


Stop Output Volt:  
If voltage-based control is selected, the smart load output will disconnect when the battery voltage reaches this value.

Control Start Time:  
Start of the time window during which the SOC or voltage control conditions are valid.

Control End Time:  
End of the time window during which the SOC or voltage control conditions are valid.

Note:  
Outside the defined time window, the smart load output is not restricted by SOC or voltage conditions, and will follow the same discharge behavior as the EPS output.

## Accessing Generator Data from the Home Page



Once the generator function is enabled, a generator icon will appear on the home screen. Clicking this icon will navigate to the Generator Details Page.

## Generator Details Page



### Generator

|              |              |              |
|--------------|--------------|--------------|
| L1-V: 0.0 V  | L2-V: 0.0 V  | L3-V: 0.0 V  |
| L1-I: 0.0 A  | L2-I: 0.0 A  | L3-I: 0.0 A  |
| L1-P: 0.0 kW | L2-P: 0.0 kW | L3-P: 0.0 kW |

Today: 0.0 kWh    Total: 0.0 kWh

Total Power: 0.0 kW



L1 / L2 / L3:  
Displays the voltage, current, and power of each phase.

Additional Information:

Today's Generated Energy

Total Historical Generation

Total Generator Power Output

## 8.10 Advanced Settings Menu

This page allows configuration of parallel settings, Wi-Fi baud rate, and EMS communication parameters.



### Advanced Function

|               |          |
|---------------|----------|
| Parallel Type | Single   |
| Parallel Num  | 1        |
| Parallel Addr | 1        |
| WiFi Baud     | 19200    |
| EMS Port      | AFCL_485 |
| EMS Baud      | 19200    |



**2. Wi-Fi Baud:**  
Baud rate for communication between inverter and data logger.

**EMS Port:**  
Designates the spare RS485 port on the inverter for EMS (Energy Management System) communication.  
Default setting: AFCL\_485 (can be changed based on actual use).

**EMS Baud:**  
Sets the communication baud rate for the EMS Port.  
Default value: 19200.

**1. Parallel Settings**  
**Parallel Type:**  
Sets the parallel operation mode of the system.

**Parallel Num:**  
Specifies the total number of inverters in the system (Master + Slaves).

**Parallel Addr:**  
Sets the inverter address in the system.

The master inverter is always set to address 1.

Slave inverters follow in sequential order (2, 3, ...).

**3. Parallel Configuration Screens – Example of 3-Inverter System**  
The following screenshots demonstrate how to configure a parallel system with one master inverter and two slave inverters. All settings must be consistent across devices, except for Parallel Addr, which should be unique per unit.

(1)Master Inverter Configuration

| Advanced Function |          |
|-------------------|----------|
| Parallel Type     | Master   |
| Parallel Num      | 3        |
| Parallel Addr     | 1        |
| WiFi Baud         | 19200    |
| EMS Port          | AFCL_485 |
| EMS Baud          | 19200    |

Parallel Type: Master

Parallel Num: 3 (total number of inverters)

Parallel Addr: 1

Wi-Fi Baud: 19200

EMS Port: AFCL\_485

EMS Baud: 19200

This inverter is designated as the master unit, responsible for synchronization and control across the entire system.

(2) Slave Inverter 1 Configuration

| Advanced Function |          |
|-------------------|----------|
| Parallel Type     | Slave    |
| Parallel Num      | 3        |
| Parallel Addr     | 2        |
| WiFi Baud         | 19200    |
| EMS Port          | AFCL_485 |
| EMS Baud          | 19200    |

Parallel Type: Slave

Parallel Num: 3

Parallel Addr: 2

Wi-Fi Baud: 19200

EMS Port: AFCL\_485

EMS Baud: 19200

This inverter operates as Slave 1, assigned address 2.

(3)Slave Inverter 2 Configuration

| Advanced Function |          |
|-------------------|----------|
| Parallel Type     | Slave    |
| Parallel Num      | 3        |
| Parallel Addr     | 3        |
| WiFi Baud         | 19200    |
| EMS Port          | AFCL_485 |
| EMS Baud          | 19200    |

Parallel Type: Slave

Parallel Num: 3

Parallel Addr: 3

Wi-Fi Baud: 19200

EMS Port: AFCL\_485

EMS Baud: 19200

This inverter operates as Slave 2, assigned address 3.

-Important Notes:

1.  
All inverters must have the same Wi-Fi Baud rate and EMS Baud rate.
2.  
Ensure proper wiring and grounding between all units.
3.  
Make sure firmware versions are consistent across all inverters.
4.  
Communication cables (e.g. RS485 or CAN) must be securely connected.

8.11 Record Menu

Records

Current Faults

History Faults

Operate Logs

Current Fault

| Occurred          | Alarms Code            |  |
|-------------------|------------------------|--|
| 23/11/10 12:03:26 | F66-arm-inv comm lost  |  |
| 23/11/10 12:03:26 | F67-arm-dcdc comm lost |  |
| 23/11/10 12:04:16 | F68-wifi comm lost     |  |
|                   |                        |  |

1/1

History Fault

| Occurred        | Alarms Code            |  |
|-----------------|------------------------|--|
| '11/15 05:38:58 | F67 arm-dcdc comm lost |  |
| '11/15 05:38:58 | F66 arm-inv comm lost  |  |
| 11/10 17:50:28  | F67 arm-dcdc comm lost |  |
| 11/10 17:50:28  | F66 arm-inv comm lost  |  |
| 1/10 13:11:50 0 | F68 wifi comm lost     |  |
| 0 13:10:50 23:  | F67 arm-dcdc comm lost |  |

1/184

Operate Logs

| Occurred          | Description   |  |
|-------------------|---------------|--|
| 23/11/01 14:19:54 | INV power off |  |
| 23/11/01 14:19:53 | System start  |  |
| 23/11/01 14:19:26 | INV power off |  |
| 23/11/01 14:19:25 | System start  |  |
| 23/11/01 14:18:55 | INV power off |  |
| 23/11/01 14:18:54 | System start  |  |

1/72

**Fault and Operation Logs**

**Current Fault:**  
Displays the inverter’s active faults and alarms. It includes the timestamp, fault code, and fault description of the current issue.

**History Fault:**  
Shows the inverter’s fault and alarm history. It records the start time, recovery time, and details of each fault event.

**Operate Logs:**  
Contains logs of user operations such as changing inverter modes, powering the system on/off, or adjusting system settings. These logs are useful for tracking system changes and user actions.

## 8.12 Device Info Setup Menu

### Device Info

---

Device type:

Rated Power:

SN:

Model:

ARM: L1.05

INV:

DCDC:

Run Time: 00 : 00 : 01 : 56

This page displays basic information about the inverter, including:

**Device Type:**The category or class of the inverter.

**Model Number:**The specific model identifier.

**Serial Number:**The unique identifier assigned to each unit.

**Software Version:**The currently installed firmware/software version.(ARM,INV,DCDC)

**Run Time:**Total runtime of the inverter since initial operation.

This page is useful for system diagnostics, firmware tracking, and technical support.

## 8.13 Factory Setting Menu

*Reserved: This function is reserved. It is not recommended. Please inform the manufacturer/installer before setting up*

 Factory Setting 1/3

|               |                                 |                |                                 |                                                                                   |
|---------------|---------------------------------|----------------|---------------------------------|-----------------------------------------------------------------------------------|
| DRM           | <input type="text" value="No"/> | Preventive PID | <input type="text" value="No"/> |  |
| Factory Reset | <input type="text" value="No"/> | Active island  | <input type="text" value="No"/> |                                                                                   |
| AFCI          | <input type="text" value="No"/> | BatTempCompen  | <input type="text" value="No"/> |  |
| Bat Warn      | <input type="text" value="No"/> | Bat Wake-up    | <input type="text" value="No"/> |  |
| GRID Warn     | <input type="text" value="No"/> | ISO            | <input type="text" value="No"/> |  |
| Ext-Control   | <input type="text" value="No"/> | Leakage Curr   | <input type="text" value="No"/> |                                                                                   |

 Factory Setting 2/3

|                  |                                 |                |                                      |                                                                                     |
|------------------|---------------------------------|----------------|--------------------------------------|-------------------------------------------------------------------------------------|
| Device Reset     | <input type="text" value="No"/> | MPPT Ctrl Mode | <input type="text" value="CVT"/>     |    |
| Record Clear     | <input type="text" value="No"/> | MPPT Para Mode | <input type="text" value="Indepec"/> |    |
| AFCI Alarm Clear | <input type="text" value="No"/> | MPPT Num       | <input type="text" value="4"/>       |                                                                                     |
| Relay self-test  | <input type="text" value="No"/> | MPPT Power     | <input type="text" value="0 kW"/>    |   |
| Device lock      | <input type="text" value="No"/> | MPPT Disturbed | <input type="text" value="0"/>       |  |
| Exec quick       | <input type="text" value="No"/> | CVT Volt       | <input type="text" value="0 V"/>     |  |

 Factory Setting 3/3

|                 |                                 |                                     |                                 |                                                                                     |
|-----------------|---------------------------------|-------------------------------------|---------------------------------|-------------------------------------------------------------------------------------|
| Bypass          | <input type="text" value="No"/> | Each Phase Ctrl                     | <input type="text" value="No"/> |  |
| Weak Grid       | <input type="text" value="No"/> |                                     |                                 |                                                                                     |
| Schedule Enable | <input type="text" value="No"/> |                                     |                                 |  |
| Schedule Power  | <input type="text" value="Ch"/> | <input type="text" value="0.0 kW"/> |                                 |                                                                                     |
|                 |                                 |                                     |                                 |  |
|                 |                                 |                                     |                                 |  |

## 9. Trouble Shooting

This section contains information and procedures for solving possible problems with the SSL-8-24K-P3EU series inverters, and provides you with trouble shooting tips to identify and solve most problems that could occur with the SSL-8-24K-P3EU series inverters.

This section will help you narrow down the source of any problems you may encounter. Please read the following trouble shooting steps.

Check the warning or fault messages on the System Control Panel or Fault codes on the inverter information panel. If a message is displayed, record it before doing anything further. Attempt the solution indicated in below table.

| Error code | Description              | Solutions                                                                                                                                                                                                   |
|------------|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F01        | inv over volt            | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F02        | inv under volt           |                                                                                                                                                                                                             |
| F03        | short circuit            |                                                                                                                                                                                                             |
| F04        | inv over curr            |                                                                                                                                                                                                             |
| F05        | over load                | If the load power is too high or the device is downgraded, please reduce the power consumption.<br>Or seek our help if you are unable to return to a normal state.                                          |
| F07        | inv bus over volt        | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F08        | inv bus under volt       |                                                                                                                                                                                                             |
| F09        | bus unbalance            |                                                                                                                                                                                                             |
| F10        | leakage self-test fail   |                                                                                                                                                                                                             |
| F11        | leakage over limit       |                                                                                                                                                                                                             |
| F12        | relay self-test fail     | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F13        | inv locked               |                                                                                                                                                                                                             |
| F14        | busbar buffer fail       |                                                                                                                                                                                                             |
| F15        | inv over temp            | Check whether the parallel communication cable is properly connected. Or seek help from us, if not go back to normal state.                                                                                 |
| F17        | parallel total count err |                                                                                                                                                                                                             |
| F18        | parallel comm fail       |                                                                                                                                                                                                             |
| F19        | parallel SW mismatch     |                                                                                                                                                                                                             |
| F20        | parallel HW mismatch     |                                                                                                                                                                                                             |
| F21        | parallel model mismatch  |                                                                                                                                                                                                             |
| F22        | parallel para sync       |                                                                                                                                                                                                             |
| F23        | master conflict          |                                                                                                                                                                                                             |
| F24        | slave id conflict        |                                                                                                                                                                                                             |
| F25        | parallel signal err      |                                                                                                                                                                                                             |
| F26        | master no slave          |                                                                                                                                                                                                             |

|     |                            |                                                                                                                                                                                                                                                                                       |
|-----|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F33 | inv flash fault            | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state.                                               |
| F34 | inv-dc comm fault          |                                                                                                                                                                                                                                                                                       |
| F35 | inv phase-locked           |                                                                                                                                                                                                                                                                                       |
| F36 | inner para match fail      |                                                                                                                                                                                                                                                                                       |
| F37 | self-test fail(Italy)      |                                                                                                                                                                                                                                                                                       |
| F38 | inv master fault           |                                                                                                                                                                                                                                                                                       |
| F39 | inv parallel comm fail     |                                                                                                                                                                                                                                                                                       |
| F40 | inv parallel signal err    |                                                                                                                                                                                                                                                                                       |
| F41 | inv curr DC component high |                                                                                                                                                                                                                                                                                       |
| F42 | inv parallel overload      |                                                                                                                                                                                                                                                                                       |
| F43 | inv load curr unbalance    |                                                                                                                                                                                                                                                                                       |
| F44 | inv parallel system fault  |                                                                                                                                                                                                                                                                                       |
| F49 | dc bus over volt           | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state.                                                                            |
| F50 | dc bus under volt          |                                                                                                                                                                                                                                                                                       |
| F51 | midbus over volt           |                                                                                                                                                                                                                                                                                       |
| F52 | midbus under volt          |                                                                                                                                                                                                                                                                                       |
| F53 | dc bat disch OC            |                                                                                                                                                                                                                                                                                       |
| F54 | dc bat ch OC               |                                                                                                                                                                                                                                                                                       |
| F55 | LLC HW over curr           |                                                                                                                                                                                                                                                                                       |
| F56 | dc bat over volt           |                                                                                                                                                                                                                                                                                       |
| F57 | dc bat under volt          |                                                                                                                                                                                                                                                                                       |
| F60 | bat reverse connect        | Check whether the positive and negative terminals of the battery power line are connected in reverse mode.                                                                                                                                                                            |
| F63 | dc over temp               | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| F65 | meter comm lost            | Check whether the meter communication line is normal.                                                                                                                                                                                                                                 |
| F66 | arm-inv comm lost          | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state.                                               |
| F67 | arm-dcdc comm lost         |                                                                                                                                                                                                                                                                                       |
| F68 | Wi-Fi comm lost            | Please check Wi-Fi LED light status.Or seek help from us, if not go back to normal state.                                                                                                                                                                                             |
| F69 | bms1-can comm lost         | Make sure the battery you use is compatible with the inverter. Check whether the communication cables or ports between the battery and the inverter are properly connected                                                                                                            |

| F70          | dsp para match err  | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state.                                               |
|--------------|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F71          | EPO                 | Seek help from us, if not go back to normal state.                                                                                                                                                                                                                                    |
| F72          | ambient temp high   | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| F73          | bms1-485 comm lost  | Make sure the battery you use is compatible with the inverter. Check whether the communication cables or ports between the battery and the inverter are properly connected                                                                                                            |
| F74          | arm flash error     | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state.                                               |
| F75          | NTC disconnect      |                                                                                                                                                                                                                                                                                       |
| F76          | dsp para set fail   |                                                                                                                                                                                                                                                                                       |
| F81          | dc-inv comm lost    |                                                                                                                                                                                                                                                                                       |
| F82          | dc flash fault      |                                                                                                                                                                                                                                                                                       |
| F83          | dc fault locked     |                                                                                                                                                                                                                                                                                       |
| F84          | 12V aux fault       | Seek help from us, if not go back to normal state.                                                                                                                                                                                                                                    |
| F87          | PV1 over volt       | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state.                                                                            |
| F88          | PV2 over volt       |                                                                                                                                                                                                                                                                                       |
| F89          | PV1 over curr       |                                                                                                                                                                                                                                                                                       |
| F90          | PV2 over curr       |                                                                                                                                                                                                                                                                                       |
| F91          | PV1 reverse connect | Check whether the PV cables are correctly connected.                                                                                                                                                                                                                                  |
| F92          | PV2 reverse connect |                                                                                                                                                                                                                                                                                       |
| F96          | ISO fault           | Seek help from us, if not go back to normal state.                                                                                                                                                                                                                                    |
| Warning code | Description         | Solutions                                                                                                                                                                                                                                                                             |
| W01          | over load           | If the load power is too high or the device is downgraded, please reduce the power consumption.<br>Or seek our help if you are unable to return to a normal state.                                                                                                                    |

|     |                                   |                                                                                                                                                                                                                                                                                       |
|-----|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| W02 | inv over temp                     | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| W03 | grid over freq                    | <p>If the power grid is abnormal, the inverter automatically returns to the normal working state after the power grid recovers.</p> <p>Or seek help from us, if not go back to normal state.</p> <p>*GARDA(Power grid amplitude quick check alarm)</p>                                |
| W04 | grid under freq                   |                                                                                                                                                                                                                                                                                       |
| W05 | grid over volt                    |                                                                                                                                                                                                                                                                                       |
| W06 | grid under volt                   |                                                                                                                                                                                                                                                                                       |
| W07 | grid lost phase                   |                                                                                                                                                                                                                                                                                       |
| W08 | grid long time OV                 |                                                                                                                                                                                                                                                                                       |
| W09 | grid phase error                  |                                                                                                                                                                                                                                                                                       |
| W10 | GARDA                             |                                                                                                                                                                                                                                                                                       |
| W11 | grid DC component rapid detection |                                                                                                                                                                                                                                                                                       |
| W12 | grid phase rapid inspection       |                                                                                                                                                                                                                                                                                       |
| W13 | dc bat over volt                  | <p>If the internal fault of the lithium battery occurs, Turn off the PV, grid, and battery, and wait 5 minutes to turn on the inverter and lithium battery. Check whether the problem is resolved. Or seek help from us, if not go back to normal state.</p>                          |
| W14 | dc bat under volt                 |                                                                                                                                                                                                                                                                                       |
| W15 | bat none-connected                | <p>The inverter does not detect the battery voltage. Ensure that the battery switch system is started and cables are properly connected.</p>                                                                                                                                          |
| W16 | dc over temp                      | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| W17 | soc1 low                          | <p>Check Battery communication status.Or seek help from us, if not go back to normal state.</p>                                                                                                                                                                                       |
| W18 | bat ch&disch limit                |                                                                                                                                                                                                                                                                                       |
| W21 | PV1 under volt                    | <p>Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter.</p> <p>Check whether the problem is resolved.Or seek help from us, if not go back to normal state.</p>                                                                                      |
| W22 | PV2 under volt                    |                                                                                                                                                                                                                                                                                       |

|     |                    |                                                                                                                                                                                                                                                                                                                                                                 |
|-----|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| W28 | gen volt abnormal  | <p>Measure the generator output voltage using a multimeter.</p> <p>Ensure the generator is operating within its rated voltage (typically 220/230V or 380/400V depending on the system).</p> <p>Check for loose or faulty wiring between the generator and inverter input.</p>                                                                                   |
| W29 | gen freq abnormal  | <p>Check the generator frequency output with a frequency meter.</p> <p>Make sure the generator engine speed is stable (RPM too high or low will affect frequency).</p> <p>Adjust the engine governor if needed.</p> <p>Avoid overloading the generator, which may cause frequency fluctuations.</p>                                                             |
| W30 | gen phase abnormal | <p>Verify the phase sequence (e.g., R-S-T) using a phase rotation tester.</p> <p>Ensure all generator output phases are properly connected and no wires are loose or damaged.</p> <p>Check for any single-phase load imbalance or internal generator phase loss.</p> <p>For three-phase systems, confirm that generator and inverter phase sequences match.</p> |
| W31 | slave comm fail    | <p>Check parallel settings. Or seek help from us, if not go back to normal state.</p>                                                                                                                                                                                                                                                                           |

#### NOTICE

If your inverter's information panel is not displaying a Fault light, check the following list to make sure that the present state of the installation allows proper operation of the unit.

Is the inverter located in a clean, dry, and adequately ventilated place?

Have the DC input breakers been opened?

Are the cables adequately sized and short enough?

Are the input and output connections and wiring in good condition?

Are the configuration settings correct for your particular installation?

Are the display panel and the communications cable properly connected and undamaged?

Contact Customer Service for further assistance. Please be prepared to describe details of your system installation and provide the model and serial number of the unit.

## 10. Maintenance

### 10.1 Power ON the Inverter for first time



Important: Please follow these steps to turn on the inverter.

Step 1: Press the Power on/off button to turn on the device, and keep the button pressed.

Step 2: make the PV SWITCH to the ON position.

Step 3: Turn on the battery. Turn on the DC switch between battery and inverter.

Step 4: Turn on the AC circuit breaker between the inverter port and the power grid.

Step 5: Open the AC circuit breaker between the inverter load port and the emergency load.

Step 6: Manually send the startup command through the APP (for safety, it can be set to automatic startup after the initial power-on).

Step 7: The inverter should start running now.

### 10.2 Power Off the Inverter



- Power off the inverter before operations and maintenance. Otherwise, the inverter may shocks or occur.
- Delayed discharge. Wait until the components are discharged after power off.

Step 1: Turn off the AC breaker on the ON-GRID side of the inverter.

Step 2: Turn off the AC breaker on the BACK-UP side of the inverter.

Step 3: Turn off the battery breaker between the inverter and the battery.

Step 4: Turn off the PV switch of the inverter.

### 10.3 Removing the Inverter



- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

Step 1: Disconnect all the cables, including DC cables, AC cables, communication cables, the communication module, and PE cables.

Step 2: Remove the inverter from the mounting plate.

Step 3: Remove the mounting plate.

Step 4: Store the inverter properly. If the inverter needs to be used later, ensure that the storage conditions meet the requirements.

## 10.4 Disposing of the Inverter

If the inverter cannot work anymore, dispose of it according to the local disposal requirements,  
The inverter cannot be disposed of together with household waste.



- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

## 10.5 Routine Maintenance

| Maintaining Item      | Maintaining Method                                                                                                                | Maintaining Period |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------|--------------------|
| System Clean          | Check the heat sink, air intake, and air outlet for foreign matter or dust.                                                       | Once 6-12 months   |
| PV Switch             | Turn the DC switch on and off ten consecutive times to make sure that it is working properly.                                     | Once a year        |
| Electrical Connection | Check whether the cables are securely connected. Check whether the cables are broken or whether there is any exposed copper core. | Once 6-12 months   |
| Sealing               | Check whether all the terminals and ports are properly sealed. Reseal the cable hole if it is not sealed or too big.              | Once a year        |



---

**Shenzhen UZ Energy Limited**

Add: Floor 1, Building 1, ZhongYunTai Industry Park, Songbai Rd, Shiyan St, Bao'an District, Shenzhen, Guangdong, China

Tel: 86-755-88609397

E-mail: [marketing@uzenergy.com](mailto:marketing@uzenergy.com)

<http://www.uzenergy.com>